



M660/M663/M661 Advanced Panel Meter/Transducer

User Manual



October 15, 2019
ML0042 Document Revision K
© 2019 by Bitronics, LLC

TABLE OF CONTENTS

60 SERIES MANUAL SET	6
VERSION HISTORY (ABRIDGED)	6
CERTIFICATION.....	7
INSTALLATION AND MAINTENANCE	7
WARRANTY AND ASSISTANCE	7
AUTHORIZED REPRESENTATIVE IN THE EUROPEAN UNION.....	8
COPYRIGHT NOTICE	8
TRADEMARKS.....	8
SAFETY SECTION	9
Health and safety	9
Explanation of symbols and labels	9
WARNING: EMISSIONS – CLASS A DEVICE (EN55011)	11
DECOMMISSIONING AND DISPOSAL.....	11
1.0 DESCRIPTION & SPECIFICATIONS.....	13
1.1 Introduction	13
1.2 Features.....	13
1.3 Specifications.....	13
1.4 Standards and Certifications	20
1.4.1 Revenue	20
1.5 Environment.....	20
2.0 PHYSICAL CONSTRUCTION & MOUNTING.....	24
2.1 Installation.....	27
2.2 Initial Inspection	27
2.3 Protective Ground/Earth Connections	27
2.4 Overcurrent Protection.....	27
2.5 Supply/Mains Disconnect	27
2.6 Instrument Mounting	27
2.7 Cleaning.....	28
3.0 BACK PANEL & WIRING.....	29
3.1 Auxiliary Power	30
3.1.1 Specifications (per section 1.3).....	30
3.2 VT Inputs – VA, VB, VC, VN (See Appendix A1 and Section 1.3)	31
3.3 CT Inputs – IA, IB, IC (See Appendix A1 and section 1.3).....	31
3.4 Ethernet	32
3.4.1 Network settings	32
3.4.2 Indicators – Ethernet (ACT) & Fiber LEDs	34
3.4.3 Firmware upgrades and saving and loading configuration files – Ethernet service port.....	34
3.5 Optional Serial Port.....	36
3.5.1 RS232/485 Connections	37

3.6 Optional Energy Pulse Outputs	40
4.0 OPERATION	43
4.1 Display	43
4.1.1 Overview – Buttons Functions.....	55
4.1.2 Keypad Functions for Display Mode.....	56
4.1.3 Display Error Messages	57
5.0 FUNCTIONAL DESCRIPTION	58
5.1 Configuration	58
5.2 HTML Web Server	58
5.3 Passwords	58
5.4 Using the M66X with a Bitronics Analog Output Converter.....	59
5.5 Navigating the M660's setup menu from the front panel.....	61
5.6 Performing set-up through the web page interface	66
6.0 MEASUREMENTS.....	91
6.1 Changing Transformer Ratios.....	91
6.2 Current.....	91
6.2.1 Residual Current.....	91
6.3 Voltage Channels	92
6.4 Voltage Aux	92
6.5 Power Factor	92
6.6 Watts / Volt-Amperes (VAs) / VARs (Uncompensated).....	92
6.6.1 Geometric VA Calculations	93
6.7 Compensated Watts and VARs (Line and Transformer Loss Compensation).....	95
6.8 Energy.....	96
6.9 Frequency	97
6.10 Demand Measurements	97
6.10.1 Ampere and Fundamental Ampere Demand	98
6.10.2 Volt Demand.....	98
6.10.3 Power Demands (Total Watts, VARs, and VAs)	98
6.10.4 Demand Resets.....	98
6.10.5 Demand Interval	99
6.11 Harmonic Measurements.....	99
6.11.1 Voltage Distortion (THD)	99
6.11.2 Current Distortion (THD and TDD).....	99
6.11.3 Fundamental Current	100
6.11.4 Fundamental Voltage	100
6.11.5 K-Factor.....	101
6.11.6 Displacement Power Factor	101
6.11.7 Phase Angles	101
6.12 Heartbeat and Health Check	102
6.13 List of Available Measurements & Settings	103
6.14 Calibration.....	103
6.15 Instantaneous Measurement Principles	104
6.15.1 Sampling Rate and System Frequency.....	104
APPENDIX	105
A1 CT/VT Connection Diagrams	105
A2 Ethernet Troubleshooting	109
A3 Display Screens – Visual Representations (M660).....	110

60 SERIES MANUAL SET

ML0042	M66x Family User Manual
ML0036	50/60 Series DNP3 Protocol
ML0037	50/60 Series Modbus Protocol
ML0043	M66x IEC 61850 Protocol Manual
ML0048	PowerPlex II and 60 Series EtherNet/IP Protocol Manual
ML0049	M661P3 Pole Top User Manual

VERSION HISTORY (ABRIDGED)

V1.00	2014-07-14	Initial release
V2.00	2014-11-25	Feature upgrades
V2.01	2015-02-13	Added configurable TCP keepalive time setting, added status tab to web UI, added IEC61850 enable/disable control
V2.02	2015-03-13	Added support for IEC61850 Edition 2, 100 Mb fiber
V2.07	2015-07-01	Updated both editions of ICD files as well as associated built-in demo CID files to v1.03
V2.08	2015-07-08	Maintenance upgrade
V2.09	2015-11-24	New Ed1 & Ed2 ICD files and new CID demo files, ver 1.06
V2.10	2015-12-22	Maintenance upgrade
V2.11	2016-01-29	Updated IEC61850 factory ICD and CID files to v1.07
V2.12	2016-02-22	Maintenance upgrade
V2.20	2016-10-07	Allows client-initiated requests using MMS version2; support to IEC61850 for measurement specific timestamps; added voltage & current average measurements
V2.21	2016-10-26	Energy resets can now be configured as Class 1, 2, or 3 events
V2.24	2017-08-15	Added Average L-L Volts, Average L-N Volts, and Average Amps to protocols
V2.25.0	2017-11-15	Added trend recorder
V2.28.0	2018-04-04	Support for pole-top feature
V2.30.0	2018-05-16	Support for EtherNet/IP protocol
V2.31.0	2018-06-29	Support for EtherNet/IP protocol in 60 Series
V2.40.0	2019-01-25	Support for pulse output; additional features for M661P3
V2.41.0	2019-04-03	True RMA V, A, W measurements for pole-top P3 variant
V2.42.0	2019-05-31	Support for 20mA input option, web server enhancements
V2.51.0	2019-10-11	Support for 24 Vdc power supply, web server improvements

CERTIFICATION

Bitronics LLC certifies that the calibration of our products is based on measurements using equipment whose calibration is traceable to the United States National Institute of Standards Technology (NIST).

INSTALLATION AND MAINTENANCE

Bitronics LLC products are designed for ease of installation and maintenance. As with any product of this nature, installation and maintenance can present electrical hazards and should be performed only by properly trained and qualified personnel. If the equipment is used in a manner not specified by Bitronics LLC, the protection provided by the equipment may be impaired.

In order to maintain UL recognition, the following Conditions of Acceptability shall apply:

a) After installation, all hazardous live parts shall be protected from contact by personnel or enclosed in a suitable enclosure.

WARRANTY AND ASSISTANCE

This product is warranted against defects in materials and workmanship for a period of one-hundred-and-twenty (120) months from the date of their original shipment from the factory. Products repaired at the factory are likewise warranted for eighteen (18) months from the date the repaired product is shipped, or for the remainder of the product's original warranty, whichever is greater. Obligation under this warranty is limited to repairing or replacing, at our designated facility, any part or parts that our examination shows to be defective. Warranties only apply to products subject to normal use and service. There are no warranties, obligations, liabilities for consequential damages, or other liabilities on the part of Bitronics LLC except this warranty covering the repair of defective materials. The warranties of merchantability and fitness for a particular purpose are expressly excluded.

For assistance, contact Bitronics LLC at:

Telephone: 610.997.5100
Fax: 610.997.5450
Email: bitronics@novatechweb.com
Website: www.novatechweb.com/bitronics

Shipping:
261 Brodhead Road
Bethlehem, PA 18017-8698
USA

AUTHORIZED REPRESENTATIVE IN THE EUROPEAN UNION

NovaTech Europe BVBA

Kontichsesteenweg 71

2630 Aartselaar

Belgium

T +32.3.458.0807

F +32.3.458.1817

E info.europe@novatechweb.com

COPYRIGHT NOTICE

This manual is copyrighted and all rights are reserved. The distribution and sale of this manual is intended for the use of the original purchaser or his agents. This document may not, in whole or part, be copied, photocopied, reproduced, translated or reduced to any electronic medium or machine-readable form without prior consent of Bitronics LLC, except for use by the original purchaser.

The product described by this manual contains hardware and software that is protected by copyrights owned by one or more of the following entities:

Bitronics, LLC, 261 Brodhead Road, Bethlehem, PA 18017

Schneider Automation, Inc., One High Street, North Andover, MA 01845

Triangle MicroWorks, Inc., 2213 Middlefield Court, Raleigh, NC 27615

Freescale Semiconductor, Inc., 6501 William Cannon Drive West, Austin, TX 78735

gzip inflation uses code Copyright 2002-2008 Mark Adler

inarp uses WinPcap, which is Copyright 1999-2005 NetGroup, Politecnico di Torino (Italy), and 2005-2010 CACE Technologies, Davis (California).

TRADEMARKS

The following are trademarks or registered trademarks of Bitronics, LLC:

Bitronics logo	Bitronics	PowerPlex	Triplex	Triple-II
MultiComm	PowerServe	SubCycle Technology	SubCycleStuf	

The following are trademarks or registered trademarks of the DNP User's Group:

DNP DNP3

The following are trademarks or registered trademarks of Schneider Automation, Inc.:

MODSOFT	Modicon	Modbus Plus	Modbus	Compact 984 PLC
---------	---------	-------------	--------	-----------------

SAFETY SECTION


This Safety Section should be read before commencing any work on the equipment.

Health and safety

The information in the Safety Section of the product documentation is intended to ensure that products are properly installed and handled in order to maintain them in a safe condition. It is assumed that everyone who will be associated with the equipment will be familiar with the contents of the Safety Section.

Explanation of symbols and labels

The meaning of symbols and labels that may be used on the equipment or in the product documentation is given below.



Installing, Commissioning and Servicing

Equipment connections

Personnel undertaking installation, commissioning or servicing work on this equipment should be aware of the correct working procedures to ensure safety. The product documentation should be consulted before installing, commissioning or servicing the equipment.

Terminals exposed during installation, commissioning and maintenance may present a hazardous voltage unless the equipment is electrically isolated.



If there is unlocked access to the equipment, care should be taken by all personnel to avoid electric shock or energy hazards.

Voltage and current connections should be made using insulated crimp terminations to ensure that terminal block insulation requirements are maintained for safety. To ensure that wires are correctly terminated, the correct crimp terminal and tool for the wire size should be used.

Before energizing the equipment, it must be grounded (earthed) using the protective ground (earth) terminal, or the appropriate termination of the supply plug in the case of plug connected equipment. Omitting or disconnecting the equipment ground (earth) may cause a safety hazard.

The recommended minimum ground (earth) wire size is 2.5 mm² (#12 AWG), unless otherwise stated in the technical data section of the product documentation.

Before energizing the equipment, the following should be checked:

Voltage rating and polarity

CT circuit rating and integrity of connections

Protective fuse rating

Integrity of ground (earth) connection (*where applicable*)

Equipment operating conditions

The equipment should be operated within the specified electrical and environmental limits.



Current transformer circuits

Do not open the secondary circuit of a live CT since the high voltage produced may be lethal to personnel and could damage insulation.



Insulation and dielectric strength testing

Insulation testing may leave capacitors charged up to a hazardous voltage. At the end of each part of the test, the voltage should be gradually reduced to zero, to discharge capacitors, before the test leads are disconnected.



Do not attempt to perform installation, maintenance, service or removal of this device without taking the necessary safety precautions to avoid shock hazards. De-energize all live circuit connections before work begins.



Fiber optic communication

Where fiber optic communication devices are fitted, these should not be viewed directly. Optical power meters should be used to determine the operation or signal level of the device.



WARNING: EMISSIONS – CLASS A DEVICE (EN55011)

This is a Class A industrial device. Operation of this device in a residential area may cause harmful interference, which may require the user to take adequate measures.



DECOMMISSIONING AND DISPOSAL

1. Decommissioning

The auxiliary supply circuit in the equipment may include capacitors across the supply or to ground (earth). To avoid electric shock or energy hazards, after completely isolating the supplies to the meter (both poles of any dc supply), the capacitors should be safely discharged via the external terminals before decommissioning.

2. Disposal

It is recommended that incineration and disposal to watercourses is avoided. The product should be disposed of in a safe manner. Any products containing batteries should have them removed before disposal, taking precautions to avoid short circuits. Particular regulations within the country of operation may apply to the disposal of lithium batteries.

1.0 DESCRIPTION & SPECIFICATIONS

1.1 Introduction

The M66x family of advanced panel meters/transducers provides a range of measurement and communications capabilities for 3-phase metering. They offer an outstanding display (M660), superior communications flexibility and easy setup.

The following Model M66x types are covered in this manual:

M3 - Multifunction Advanced, 3-Phase

1.2 Features

1. Full basic measurement set with optional demand and harmonic values
2. 0.2% revenue accuracy
3. Updates every 100ms
4. Optional IEC 61850 protocol or EtherNet/IP Protocol over Ethernet port
5. Ethernet protocol support for DNP3 TCP/UDP or Modbus TCP
6. Web Based configuration via standard Ethernet service port
7. Optional fiber LC 100BaseFX Ethernet port
8. Wide-range universal power supply or option for 24 Vdc
9. Rugged aluminum case
10. One model covers all wiring options
11. Standard 4" round meter (M660)
12. Standard 4" round meter mounted in either a 19" 3U rack version or a 14" wide panel mount version with 3 simultaneous displays (M663)
13. Optional RS-232/RS-485 (programmable) serial port with DNP3 or Modbus protocol
14. 3-line at once, easy-to-read, long-life LED displays (M660/M663)
15. Ultimate precision with five digits per line (M660/M663)
16. Instant recognition of the displayed function from the alphanumeric display in engineering units (M660/M663)
17. Easy setup and scrolling from front display with "Touch-Sense" buttons (M660/M663)
18. Optional trend recording
19. Optional KYZ pulse outputs

1.3 Specifications

DC PWR (Low Voltage Vdc) - Power Supply Input (Auxiliary Voltage) – terminals (+) and (-) (Intended for connection to 12V or 24V battery voltages)

Nominal: 12-40V dc

Operating Range: 8-40V dc

Burden: 5W max

Overcurrent protection (Required) : Refer to section 2.4

AUX PWR (Universal – Hi Range Power Supply) - Power Supply Input (Auxiliary Voltage) – terminals L1(+) and L2(-)

Installation Category/Overvoltage Category (Auxiliary Power Supply) – CAT II

Nominal: 48-250V dc, 69-240V ac (50/60Hz)

Operating Range: 37-300V dc, 55-275V ac (45-65Hz)

Burden: 8W max, 24VA max

Overcurrent protection (Required): Refer to section 2.4

Display: 3 lines of 5 digits, Red LED, 0.56" High (M660)
Three displays - 3 lines/5 digits, red LED, 0.56" high (M663)
1 line 8-character alphanumeric, Red LED, 0.20" High

Display Interface: 4 buttons (M660)
4 buttons in center display plus right and left buttons (M663)

Input Signals – Measurement Inputs			
CT Current Inputs	Configuration	All Input Options	3 Inputs. 3 Phase Currents (IA, IB, IC).
	Nominal	Input Option 1	1A ac
		Input Option 5	5A ac
		Input Option C	5A ac with split-core CTs
		Input Option T	5A ac
	Range	Input Option 1	0 to 2A rms continuous at all rated temperatures
		Input Option 5	0 to 10A rms continuous at all rated temperatures
		Input Option C	0 to 10A rms continuous at all rated temperatures
		Input Option T	0 to 20A rms continuous at all rated temperatures
	Overload	Input Option 1	Withstands 30A ac continuous, 400Aac for 2 seconds
		Input Option 5	Withstands 30A ac continuous, 400Aac for 2 seconds
		Input Option C	Not applicable
		Input Option T	Withstands 30A ac continuous, 400Aac for 2 seconds
	Isolation	Input Option 1	2500V ac, minimum.
		Input Option 5	2500V ac, minimum.
		Input Option C	2500V ac, minimum with external split-core current transformers.
		Input Option T	2500V ac, minimum.
	Burden	Input Option 1	0.0016VA @ 1A rms, 60Hz (0.0016ohms @ 60Hz)
		Input Option 5	0.04VA @ 5A rms, 60Hz (0.0016ohms @ 60Hz)
		Input Option C	Not applicable
		Input Option T	0.04VA @ 5A rms, 60Hz (0.0016ohms @ 60Hz)
	Frequency	All Input Options	45-65 Hz
VT (PT) Voltage Inputs	Configuration		4 Inputs, Measures 1 Bus, 3 or 4 Wire. 3 Phase Voltages (VA, VB, VC, VN). See Appendix A1 Connection Diagrams.
	Nominal		120Vac

Input Signals – Measurement Inputs

	Range		0 to 150V rms
	System Voltage		Intended for use on nominal system voltages up to 208 V rms, phase-to-phase (120V rms, phase-to-neutral).
	Common Mode Input Voltage		Reads to 400V peak, any input-to-case (ground)
	Impedance		>12M ohms, input-to-case (ground)
	Voltage Withstand		2.5kV rms 1min, input-to-case (ground) 2kV rms 1min, input-to-input
	Frequency		45-65 Hz

Sampling System


Sample Rate	64 samples per cycle	
Data Update Rate	Amps, Volts	Available every 100 ms
	Watts, VAs, VARs, PF	Available every 100 ms
Number of Bits	16	

Accuracy		
Accuracies are specified at nominal Frequency and 25C, (unless otherwise noted). Unless noted, all values are true RMS and include Harmonics to the 31st (minimum).		
Voltage		AC: Better than 0.1% of reading (20 to 150 V rms, input-to-case). (+/- 25ppm/DegC)
Voltage Aux	Only included with meters manufactured with the monitoring option	AC/DC: Better than 1.0% of reading
Current	Input option 1 (Internal Isolation - 1A ac)	Better than 0.1% of reading +/- 20uA (>0.1A to 2.0A, -20C to 70C)
		Better than 0.1% of reading +/- 50uA (0.01A to 0.1A, -20C to 70C)
		Minimum reading 1mA
	Input option 5 (Internal Isolation - 5A ac)	Better than 0.1% of reading +/- 100uA (>0.5A to 10.0A, -20C to 70C)
		Better than 0.1% of reading +/- 250uA (0.05A to 0.5A, -20C to 70C)
		Minimum reading 5mA
	Input Option T	Better than 0.1% of reading +/- 100uA (>1.0A to 10.0A, -20C to 70C)
		Better than 0.1% of reading +/- 2mA (0.05A to 1.0A, -20C to 70C)
		Minimum reading 10mA
Frequency		+/- 0.001 Hertz
Power		Meets or exceeds IEC 62053-22, -23, 0.2S

Communication Ports		
Ethernet		Single port; copper 10/100 Base-TX (standard)
		Single port; LC fiber 100 Base-FX (option)
Serial (option)		RS-232, RS-485, Software configurable ports
		Baud rate: 9600 bps to 115.2 kbps

Environmental		
Operating Temperature		-40C to 70C

Relative Humidity	0-95% non-condensing
Measurement Inputs (VTs, CTs) Installation/Measurement Category	CAT III (Distribution Level) Refer to definitions below.
Pollution Degree	Pollution Degree 2 Refer to definitions below.
Enclosure Protection (to IEC60529: 2001)	Front Panel: IP 20, Rear: IP 20 When equipment is mounted in an appropriately rated protective enclosure to NEMA or IP protection classifications, as required for the installation. Ratings are applicable for enclosure category 2 (see definitions)
Altitude	Up to and including 2000m above sea level
Intended Use	Indoor use; Indoor/Outdoor use when mounted in an appropriately rated protective enclosure to NEMA or IP protection classifications, as required for the installation. Class 1 equipment to IEC61140: 2001

Physical		
Connections 	Protective Conductor Terminal	10-32 Studs for connection with protective earth ground. Recommended Torque: 12 In-Lbs, 1.36 N-m Cable temperature rating: 85C minimum
	Current (CT)	Internal Isolation - Current Input Option 1 or 5. 10-32 Studs for current inputs. Recommended Torque: 12 In-Lbs, 1.36 N-m Cable temperature rating: 85C minimum
		External Split-Core CTs – Current Input Option C: Terminal Block accepts #22-12 AWG (0.35 to 3.3mm ²) wire, or terminal lugs up to 0.325" (8.26mm) wide. Recommended Torque: 9 In-Lbs, 1.02 N-m Cable temperature rating: 85C minimum
	Voltage (VT) & (AUX PWR)	Terminal Block accepts #22-10 AWG (0.35 to 5mm ²) wire, or terminal lugs up to 0.375" (9.53mm) wide. Precautions must be taken to prevent shorting of lugs at the terminal block. A minimum distance of 1/8" (3mm) is recommended between uninsulated lugs to maintain insulation requirements. Recommended Torque: 9 In-Lbs, 1.02 N-m Cable temperature rating: 85C minimum
	Serial Port (optional)	6 position removable terminal block, accepts 26-14AWG solid or 26-12 AWG stranded wire. Recommended Torque 7 in-lbs, 0.79 N-m.
	Ethernet (optional)	LC connector fiber port
	Ethernet	RJ45, 8 position modular jack, Category 5 for copper connection; 100m (328 ft.) UTP (unshielded twisted pair) cable.
Weight (typical)	1.8 lbs (.8 kg)	
Size	Industry standard 4" round case, 7.0 inches long	

Definitions:

Enclosure Category 2: Enclosures where no pressure difference relative to the surrounding air is present.

Installation Category II (Overvoltage Category II) or CAT II: Equipment is intended for connection to the fixed installation of a building. The power supply to the electronic equipment is separated from other circuits, usually by a dedicated transformer for the mains power supply.

Measurement/Installation Category III (Overvoltage Category III) or CAT III: Distribution Level, fixed installation, with smaller transient overvoltages than those at the primary supply level, overhead lines, cable systems, etc.

Pollution: Any degree of foreign matter, solid, liquid, or gaseous that can result in a reduction of electric strength or surface resistivity of the insulation.

Pollution Degree 2: Only non-conductive pollution occurs except that occasionally a temporary conductivity caused by condensation is to be expected.

1.4 Standards and Certifications

1.4.1 Revenue

The M66X family of meters exceeds the accuracy requirements of ANSI C12.20 and IEC 60687 (or IEC62053-22).

Type	Nominal Current	Certification
M3	1A, 5A, (Class 2, Class 10, Class 20)	ANSI C12.20, 0.2CA IEC 62053-22, 0,2S IEC 62053-23, 0,2S (Reactive)

The M66X meters were tested for compliance with the accuracy portions of the standards only. The form factor of the M66X meters differs from the physical construction of revenue meters specified by the ANSI/IEC standards and no attempt has been made to comply with the standards in whole. Contact customer service for more information.

1.5 Environment

UL/CSA Recognized, File Number E164178
UL61010-1, Edition 3, Issue Date 2012/05/11

Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use – Part 1: General Requirements
UL61010-2-30, Edition 1 – Issue Date 2012/05/11
Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use – Part 2: Particular Requirements for Testing and Measuring Circuits

CSA C22.2 No. 61010-1-12-CAN/CSA, Edition 3, Issue Date 2012/05/01
CAN/CSA Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use – Part 1: General Requirements
CSA C22.2 No. 61010-2-30-12-CAN/CSA, Edition 1 – Issue Date 2012/05/01
Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use – Part 2-030: Particular Requirements for Testing and Measuring Circuits

If applicable, the CE mark must be prominently marked on the case label.



European Community Directive on EMC (EMCD) 2014/30/EU, superseding 2004/108/EC and Directive 91/263/EC [TTE/SES].
European Community Directive on Low Voltage (LVD) 2014/35/EU, superseding 2006/95/EC

The object of the declaration described above is in conformity with the relevant Union harmonization legislation: Directives 2004/108/EC & 2006/95/EC (until April 19th, 2016) and Directives 2014/30/EU & 2014/35/EU (from April 20th, 2016).

Product and Generic Standards

The following product and generic standards were used to establish conformity:

Low Voltage (Product Safety)

IEC 61010-1, Edition 3, Issue Date 2010
Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use – Part 1: General Requirements
IEC 61010-2-30, Edition 1 – Issue Date 2010
Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use – Part 2-030: Particular Requirements for Testing and Measuring Circuits

EMC: EN 61326-1: 2013 (Supersedes EN61326-1: 2006), EN 61000-6-2: 2005 + AC: 2005 (supersedes EN 61000-6-2:2005),
EN 61000-6-4: 2007 + A1:2011 (IEC date 2010)

Radiated Emissions Electric Field Strength

EN 55011: 2009 + A1: 2010
EN 55011: 2016
EN 61000-6-4: 2007 + A1:2011 (IEC date 2010)
Group 1, Class A
Frequency: 30 - 1000 MHz

AC Powerline Conducted Emissions

EN 55011: 2009 + A1: 2010

EN 55011: 2016

EN 61000-6-4: 2007 + A1:2011 (IEC date 2010)

Group 1, Class A

Frequency: 150 kHz – 30 MHz

Conducted Emissions, Telecommunication port (Ethernet port)

EN 55022: 2010 + AC: 2011

EN 55032: 2012 + AC: 2013

EN 55032: 2015 + AC: 2016-07

Group 1, Class A

Frequency: 150 kHz – 30 MHz

Electrostatic Discharge (ESD)

EN61000-4-2: 2009

Discharge voltage: ± 8 KV Air; ± 4 KV Contact & Additionally meets ± 6 KV Contact

Immunity to Radiated Electromagnetic Energy (Radio Frequency)

EN 61000-4-3: 2006 + A1: 2008 + A2:2010, Class III

Frequency: 80 – 1000 MHz, Amplitude: 10.0 V/m, Modulation: 80% AM @ 1 kHz

Frequency: 1400 – 2000 MHz, Amplitude: 3.0 V/m, Modulation: 80% AM @ 1 kHz

Frequency: 2000 – 2700 MHz Amplitude: 1.0 V/m Modulation: 80% AM @ 1 kHz

Digital Radio Telephones:

Frequency: 900 MHz & 1890 MHz, Amplitude: 10.0 V/m, 3.0 V/m,

Modulation: 80% AM @1kHz

Electrical Fast Transient / Burst Immunity

EN 61000-4-4: 2012 (supersedes EN 61000-4-4: 2004 + A1:2010)

Burst Frequency: 5 kHz

Amplitude, AC Power Port: ± 4 KV (Severity Level 4), exceeds ± 2 KV requirement

Amplitude, Signal Port: ± 1 KV, Additionally meets ± 2 KV (Severity Level 3)

Amplitude, Telecom ports (Ethernet): ± 1 KV

Current/Voltage Surge Immunity

EN 61000-4-5: 2014 (supersedes EN 61000-4-5: 2006)

Open Circuit Voltage: 1.2 / 50 μ s

Short Circuit Current: 8 / 20 μ s

Amplitude, AC Power Port: ± 2 KV common mode, ± 1 KV differential mode

Immunity to Conducted Disturbances Induced by Radio Frequency Fields

EN 61000-4-6: 2014 (supersedes EN 61000-4-6: 2009)

Level: 3

Frequency: 150 kHz – 80 MHz

Amplitude: 10 V rms

Modulation: 80% AM @ 1 kHz

Power Frequency Magnetic Fields

EN 61000-4-8: 2010

Amplitude: 30A/m

Frequency: 50 and 60 Hz

AC Supply Voltage Dips and Short Interruptions

EN 61000-4-11: 2004

Surge Withstand Capability Test For Protective Relays and Relay Systems

ANSI/IEEE C37.90.1: 2002 (2.5 kV oscillatory wave and 4 kV EFT)

2.0 PHYSICAL CONSTRUCTION & MOUNTING

The M66x are packaged in rugged aluminum case specifically designed to meet the harsh conditions found in utility and industrial applications.

The Front panel view for the M660 and M663 (19" rack mount version) and the mounting plate view for the M661 are shown in Figure 1. The mechanical dimensions are shown in Figures 2A and 2B.



Figure 1 – M660/M663 Front View and M661 Mounting Plate View





Figure 2A - Mounting and Overall Dimensions M660 and M661
(back panel may vary as a result of options ordered)



2.1 Installation

WARNING - INSTALLATION AND MAINTENANCE SHOULD ONLY BE PERFORMED BY PROPERLY TRAINED OR QUALIFIED PERSONNEL.

2.2 Initial Inspection

Bitronics instruments are carefully checked and "burned in" at the factory before shipment. Damage can occur however, so please check the instrument for shipping damage as it is unpacked. Notify Bitronics LLC immediately if any damage has occurred, and save any damaged shipping containers.

2.3 Protective Ground/Earth Connections

The device must be connected to Protected Earth Ground. The minimum Protective Ground wire size is 2.5 mm² (#12 AWG). Bitronics LLC recommends that all grounding be performed in accordance with ANSI/IEEE C57.13.3-1983.

2.4 Overcurrent Protection

To maintain the safety features of this product, a 3 Ampere time delay (T) fuse must be connected in series with the ungrounded/non-earthed (hot) side of the supply input prior to installation. The fuse must carry a voltage rating appropriate for the power system on which it is to be used. A 3 Ampere slow blow UL Listed fuse in an appropriate fuse holder should be used in order to maintain any UL product approval.

2.5 Supply/Mains Disconnect

Equipment shall be provided with a Supply/Mains Disconnect that can be actuated by the operator and simultaneously open both sides of the mains input line. The Disconnect should be UL Recognized in order to maintain any UL product approval. **The Disconnect should be acceptable for the application and adequately rated for the equipment.**

2.6 Instrument Mounting

The instrument may be mounted into a standard 4" round panel opening as shown in Figure 2. The unit will mount through the 4-inch round panel opening from the front. Align the four #10-32 studs attached to the flange with their appropriate mounting holes, as shown by the panel hole pattern. Use four #10-32 nuts with lock washers applied onto the studs from the back side of the panel. *Make sure that any paint or other coatings on the panel do not prevent electrical contact.*

WARNING – DO NOT over tighten the nuts on the mounting studs, **HAND** tighten with a standard nut driver, 12 inch-pounds (1.36 N-m) is recommended, **MAXIMUM** torque is 15 inch-pounds (1.69 N-m).

Several instruments may be mounted on a 19" Rack panel if desired. Three units will fit side by side on a standard 5.25" high panel. Figure 2 indicates the dimensions of the panel hole cutout. Leave adequate space surrounding the instrument when determining mounting arrangements.

2.7 Cleaning

Cleaning the exterior of the instrument shall be limited to the wiping of the instrument using a soft damp cloth applicator with cleaning agents that are not alcohol based, and are non-flammable and non-explosive.

3.0 BACK PANEL & WIRING

The rear view of the M66x is shown in figure 3A with the fiber option port shown, however, it is also possible to have a meter with a serial port or without this option port.

See Appendix A1 for detailed wiring diagrams covering the CT/VT measurement inputs. Refer to the appropriate section in this user manual when wiring either the serial communication option, or either analog transducer output option, whichever applies to the option port for your meter.




Figure 3A – Rear View M66x

3.1 Auxiliary Power

The M66x meters are powered by connections to L1(+) and L2(-). A Blue LED Power (PWR) indicator is provided on the rear panel to indicate that the unit is powered ON. It is located on the right of the rear panel.

There is an option that allows the voltage across the Auxiliary Power input voltage across terminals L1(+) and L2(-) to be monitored. This monitoring option is only found in 60 Series SCADA meters that have been manufactured with this monitoring option. Refer to the order guide to verify whether the meter is made with this monitoring option. 'V Aux' will appear on the display as a measurement for meters equipped with this monitoring option.

3.1.1 Specifications (per section 1.3)

Power Supply Input (Auxiliary) Voltage – terminals L1(+) and L2(-)

DC PWR (Low Voltage Vdc) - Power Supply Input (Auxiliary Voltage - intended for connection to 12V or 24V battery voltages)

Nominal:	12-40V dc
Operating Range:	8-40V dc
Burden:	5W max

Overcurrent protection (Required) : Refer to section 2.4

AUX PWR (Universal) - Power Supply Input (Auxiliary Voltage)

Nominal:	48-250V dc, 69-240V ac (50/60Hz)
Operating Range:	37-300V dc, 55-275V ac (45-65Hz)
Burden:	8W max, 24VA max

Overcurrent protection (Required) : Refer to section 2

3.2 VT Inputs – VA, VB, VC, VN (See Appendix A1 and Section 1.3)

The M66x meter voltage (VT) signal inputs are connected to terminals 3-6 (see Appendix A1 for specific wiring configurations). Voltage signals are measured using a 12M ohm resistor divider with a continuous voltage rating of 7kV. This ideal impedance provides a low burden load for the VT circuits supplying the signals. Grounding of VT & CT signals per ANSI/IEEE C57.13.3-1983 is recommended. The polarity of the applied signals is important to the function of the instrument.

3.3 CT Inputs – IA, IB, IC (See Appendix A1 and section 1.3)

The instrument can be connected directly to a current transformer (CT). The Current (CT) signal inputs are connected to terminals 7-12.

Several hardware options are offered for the M66x current inputs. Distinctions are based on the current option ordered and the physical constructions.

The 1 Amp and 5 Amp current inputs, current input options 1 and 5 respectively, feature 10-32 terminals to assure reliable connections. This results in a robust current input (CT) connection with negligible burden to ensure that the user's external CT circuit can't ever open-circuit, even under extreme fault conditions. Grounding of CT signals per ANSI/IEEE C57.13.3-1983 is required.

Current inputs, option 1: 1 Amp input with internal current isolation transformer, constructed with 10-32 studs as the current terminals. **(See Figure 3A for the physical construction shown for the current terminals).** It is intended that this meter connect to the output from the secondary of permanently installed Current Transformers (CTs).

WARNING: DO NOT loosen existing 10-32 hardware that secures the current input studs to the back panel. When making connections to the current input studs, use #10 ring lugs. Fasten ring lugs with the 10-32 bagged hardware (flat washer, lock washer, and nut) provided. DO NOT OVERTORQUE. HAND Tighten with a standard nut driver. 12 inch-pounds (1.36 N-m) is recommended, MAXIMUM torque is 15 inch-pounds (1.69 N-m).

Current inputs, option 5: 5 Amp input with internal current isolation transformer, constructed with 10-32 studs as the current terminals. **(See Figure 3A for the physical construction shown for the current terminals).** It is intended that this meter connect to the output from the secondary of permanently installed Current Transformers (CTs).

WARNING: DO NOT loosen existing 10-32 hardware that secures the current input studs to the back panel. When making connections to the current input studs, use #10 ring lugs. Fasten ring lugs with the 10-32 bagged hardware (flat washer, lock washer, and nut) provided. DO NOT OVERTORQUE. HAND Tighten with a standard nut

driver. 12 inch-pounds (1.36 N-m) is recommended, MAXIMUM torque is 15 inch-pounds (1.69 N-m). .

3.4 Ethernet

The M66x Ethernet port meets or exceeds all requirements of ANSI/IEEE Std 802.3 (IEC 8802-3:2000) and additionally meets the requirements of part 8-1 TCP/IP T-profile for physical layer 1 (Ethernet copper interface).

M66x are offered with a standard Ethernet 10/100 Megabit (Mb) RJ45 (copper) interface (10BASE-T and 100BASE-TX) which automatically selects the most appropriate operating conditions via auto-negotiation. This interface is capable of operating either as half-duplex (compatible with all Ethernet infrastructure) or full-duplex interfaces (which allow a potential doubling of network traffic). Note that the meters come with the port setup as a service port, with Modbus TCP/IP or DNP3 TCP/IP or UDP software offered as an option. An option to add a LC 100BASE-FX fiber port also exists operating at 1300 nm (far infra-red, full-duplex). If needed, adapters are available to convert the LC to ST connectors, the same that are used in the Bitronics 70 Series.

3.4.1 Network settings

The M66x come preconfigured for interconnection to an HTML web server with default settings for IP address, SUBNET mask, and ROUTER (GATEWAY) address.

Network Default (Preconfigured) Settings		
IP Address	Subnet mask	Router (Gateway) Address
192.168.0.171	255.255.255.0	192.168.0.1

It is very important that the network have no duplicate IP addresses, so an IP address conflict is NOT created for your network. It is recommended to perform your initial setup for network addresses using the front buttons on the meter, unless it is known that the default (preconfigured) IP address is not already an assigned address on your network. Changing the stored Configuration of these network addresses may be accomplished by using one of the following methods

Enter Network addresses using the meter's front buttons (M660):

Refer to the section in this manual on "Navigating the M660's setup menu from the Front panel" for further instruction regarding the button sequence you will use to scroll through the menu structure. This will provide a handy menu tree.

Activate the setup mode using the front buttons on the meter by pressing the Up + Toggle (Exit) buttons simultaneously. Scroll to menu selection "1.3", "Network", in order to change the Network settings. Enter an IP address that you know is an unassigned address for your network. You can ping the IP address to make sure it is

not already in use on your network. You may also want to check with your network administrator to make sure the IP address you plan on using is available to use on your network. After entering the Network addresses exit out of the menu, and when prompted to save the new configuration settings, press the button directly under the SAVE prompt identified as “Y” (Yes). Reboot the meter for the configuration changes to take effect.

Enter the IP Address for the meter through a standard web browser:

Before entering an IP address with this method make sure the current IP address and the new IP address to be assigned to the meter will not cause IP address conflicts on your local network. To connect to the web server enter the meter’s current IP Address in your web browser’s address bar. When the web server screen appears click on the “Settings” tab. Type the new Network settings (IP address, Subnet mask, Gateway) in the appropriate fields and click the “**Apply**” button to send the new network settings to the meter. Reboot the meter for the configuration change to take effect.

The M66x uses the following port numbers for each type of protocol:

Protocol	Port Number
DNP3	20000 (TCP, UDP)
HTML	80 (TCP)
Modbus	502 (TCP)

Determining the IP Address if unknown:

Although the IP address can be obtained via the display, for the M661 which does not have a display, Bitronics has created a utility program to request the IP address for a specific MAC address on an Ethernet network. This program can be used with the M660 as well. The program is available on the company website (<http://www.novatechweb.com/downloads/inarp/>).

The program uses the Inverse Address Recognition Protocol to perform the lookup and thus is called inarp. The InARP protocol definition can be found at www.apps.ietf.org/rfc/rfc2390.html. The inarp utility can also scan an Ethernet network for a range of MAC addresses, printing the IP address for any devices which respond.

The general form of inarp is defined below, followed by some usage examples.

inarp usage:

```
inarp [-i <if_ipaddr>] [-n <cnt>] [-p <ms>] [-v] <mac-spec>
```

where

```
<if_ipaddr> := interface ip address (default is 1st Ethernet interface)  
<cnt> := count of addresses to poll (default 1)
```

```

    <ms> := period between polls (100ms)
    <mac-spec> := <6ByteMac> | <[3-5]ByteMac> | <macRangeName>
    <6ByteMac> := xx:xx:xx:xx:xx:xx - <cnt> can specify a range to scan
    <5ByteMac> := xx:xx:xx:xx:xx - default <cnt> is 256
    ...
    <3ByteMac> := xx:xx:xx - default <cnt> is 16,777,216
    <macRangeName> := "60series"
        60Series MAC base (00:d0:4f:03), default <cnt> is 65,536
    -v := request verbose information

```

CTRL-C stops a scan.

The inarp utility requires the WinPcap and Packet libraries which are bundled in the WinPcap "Installer for Windows." This can be downloaded from www.winpcap.org.

Installation requires Administrator privileges.

Examples:

```

to poll the 1st IPv4 interface,
    inarp -v 60series
    CTRL-C stops the scan

```

```

to poll the IPv4 interface associated with 192.168.1.1, use
    inarp -v -i 192.168.1.1 60series

```

```

or to poll a specific mac, use
    inarp -v -i 192.168.1.1 00:D0:4F:03:00:15

```

The inarp utility is Copyright (c) 2011 by Bitronics, LLC. All rights reserved.
 Portions of inarp are
 Copyright (c) 1999 - 2005 NetGroup, Politecnico di Torino (Italy), and
 Copyright (c) 2005 - 2010 CACE Technologies, Davis (California)

3.4.2 Indicators – Ethernet (ACT) & Fiber LEDs

There are 2 LEDs on the rear panel to indicate activity is occurring on the communication ports. These LEDs are useful in determining that there is activity occurring on the ports. The "ACT" LED will flash to indicate there is activity on the Ethernet RJ45 port. It will also indicate that a link has been established. The "FIBER" LED flashes to indicate there is activity occurring for the fiber port.

A troubleshooting guide is found in Appendix A2, which may be useful in establishing Ethernet connections.

3.4.3 Firmware upgrades and saving and loading configuration files – Ethernet service port

New versions of firmware may be released by Bitronics from time to time, either to add new functionality or to correct errors in code that may have escaped detection prior to commercial release. Consult the factory for detailed information pertaining to the

availability of firmware upgrades. In cases such as this, it is desirable to support a mechanism for new firmware to be installed remotely. The ability to upgrade Firmware is done over the Ethernet port. The M66X family utilizes a page in the Web Server interface to upload and install new firmware.

The complete M66X configuration, which includes all user-configurable parameters, can be saved in a single file on your computer. This allows you to save a backup of your configuration and to restore it at a later time, as needed. This also allows you to configure one M66X and then transfer the configuration to multiple other M66X's.

Before initiating the firmware upgrade, if you are planning to use a configuration that has already been setup in the M66X, then you should first go to the Load/Store Settings page and click on the Get File button to save the IED configuration to your computer (if you will be using a default configuration this step is not necessary). Use the File Save dialog window to select the location on your computer to save the configuration file. Once you have saved the file, it is recommended that you load the file back to the M66X to validate that it was saved correctly. Click the Browse or Choose File button and use the File Open dialog window to select the configuration file you just saved. Click the Submit button. If the "Configuration upload success" message appears, the configuration file is confirmed to have saved correctly. Once the configuration file is saved to your computer, or even if you don't need to save the configuration, you should restore the meter to the factory defaults. On the Load/Store settings page, select Restore All Defaults to bring the meter back to default settings.

To upload the new firmware, first obtain a copy of the firmware image. The firmware image is a binary file, less than 1 MB in length, that can be attached to email, distributed on a CD, or downloaded from an FTP site as circumstances dictate. Place a copy of the firmware image on your computer then access the upload page from the Firmware Upload link on the Configuration Settings page.

This will take you to the Firmware Upload page, which looks like the screen capture in Figure 4.

Figure 4 – Bitronics M66X Firmware Upload Page

Once the Firmware Upload page is visible, use the Browse button to locate the firmware image on your computer. Next use the Submit button to initiate the file transfer and installation process. The instrument must be rebooted to make the new firmware active. At the completion of the file transfer and installation process, the instrument will prompt you to reset the instrument remotely by displaying the dialog box below after the firmware has been successfully installed.

It is strongly recommended that you clear your web browser's cache (delete the temporary internet files) after updating the firmware so that the new content will be loaded into your browser. Please refer to your browser's help file on how to clear the cache. A useful keyboard shortcut common to Internet Explorer, Firefox and Chrome is CONTROL + SHIFT + DELETE, which will take you directly to the relevant dialog panel. Carefully select the items to be cleared. Be sure to check the boxes that clear "temporary internet files", "cache" or "website data" and uncheck any boxes that preserve data.

If you had a previously saved configuration that you wish to now load to your M66X, you should now go back to the Load/Store Settings page and go to the top box "Select a configuration file". Click on the box "Load network settings from file" and then browse to find the configuration file you wish to load. Once selected, click on Submit, and then you will need to reboot the unit.

3.5 Optional Serial Port

The M66x has an optional serial port that is user configurable for RS232 or RS485, and support baud rates up to 115200. See section 4.4 for screen shot showing web configuration for serial port. For meters with a display, the serial port can also be setup via the front display buttons (Setup menu - ^{1.4} Serial). The RS-232 drivers support full and half duplex modes. The default configuration for the serial ports is:

Serial Port Default Setting					
Port	Protocol	Parity	Baud	IED	Physical Media
Serial	DNP 3	None	9600	1	RS-232

Serial cable requirements for RS485 connection:

Tie RS-485 cable shields (pin 18) to earth ground at one point in system.


The recommended torque rating for the terminal block wire fasteners are listed in the Physical Specifications table (section 1.3).

A Transient Voltage Suppressor (TVS) clamp device is used on the serial port as the method of protection.

3.5.1 RS232/485 Connections

Note that various protocols and services have different port connection requirements.

When making connections to serial ports for Modbus or DNP3 over RS485, 2-wire half duplex is required. This is because it is imperative to maintain a minimum time period (3 1/3 characters) from the time the transmitter shuts off to the next message on the bus in order to guarantee reliable communications. However, when using ZMODEM or connecting to the remote display, asynchronous 2-way communications are required, and therefore a 4-wire full duplex (technically RS422) connection is needed. See figure 5 below for RS485 cable wiring diagrams showing 2 wire and figure 6 for RS232 wiring.




The cable should be Belden 9841 or equivalent. The maximum cable length for RS-485 is 4000 ft. (1200m)
*Or according to manufacturer's recommendations for the equipment.

10000581


Figure 5 - Typical RS-485 Cable Wiring

Serial Port Connections in RS232 Mode


RS-232C to PC DB9F




RS-232C to PC DB25F



RS-232C to Modem DB9M



RS-232C to Modem DB25M



The cable should be Belden 9842 or equivalent.
The maximum cable length for RS 232 is 50 ft (15m).


100000000

Figure 6 – RS-232 Cable Wiring Diagram

3.6 Optional Energy Pulse Outputs

There is an option for 4 KYZ pulse outputs with common ground. Pulse output meters are consumption monitoring devices. A pulse output power meter will indicate the number of kWhs used by the system load. Historically, rotating meters could report their power information remotely, using a pair of contact closures attached to a KYZ line. In this scheme, line “K” is attached to two single-pole single-throw switches “Y” and “Z”. “Y” and “Z” open and close as the meter’s disk rotates. As the meter rotates in one direction, Y closes, then Z closes, then Y opens, then Z opens. When it rotates in the opposite direction, showing export of power, the sequence reverses. The KY element refers to a two-wire variant of KYZ, where only the K and Y wires are used in a “normally open” configuration.

The intent of both KY and KYZ elements are mainly for meter verification and the output of energy pulses are sent to an external counter.



The pulse outputs have the following specifications:

Output:

Type: Form A, SPST, solid state relay, maximum input voltage 170V, maximum current 130mA, on resistance 25 ohms

Accuracy: Long term average accuracy limited by meter (.2% class).

Max Pulse Rate: 20 pulses/sec

The output connection diagram is shown below:




Figure 7 – Pulse Output Connections

KYZ configuration in the 60 Series is achieved by navigating to the Settings / Input screen of the instrument's webserver.

KYZ Energy Counter


Enable/Disable	<input type="text" value="Enable"/>	
Energy per Pulse	<input type="text" value="20.0000"/>	KWHr/KVARh
KWHr(+) Output	<input type="text" value="OUT1"/>	
KWHr(-) Output	<input type="text" value="OUT2"/>	
KVarHr(+) Output	<input type="text" value="OUT3"/>	
KVarHr(-) Output	<input type="text" value="OUT4"/>	

When the 4 digital KYZ option is ordered, the positive and negative KWHr and KVarHr can be assigned to any of the four outputs in whatever order is desired.

Explanation of KYZ Parameters

Energy per Pulse (EPP)

- The EPP parameter has a range of 10^{-5} to 10^4 with units of KWhr / kVARhr.
- The default value of EPP is 10 KWhr / kVARhr primary engineering units.
- The time between rising edges defines the length of the energy pulse as shown below.
- Shorter pulses indicate a faster rate of consumption as shown in the stepped power square wave.



4.0 OPERATION

4.1 Display

The M660 meters can display several per-phase and total quantities for the circuit being monitored. In order to make all quantities available, the display scrolls from quantity to quantity approximately every 5 seconds. The quantities are refreshed once a second. The Alphanumeric display at the bottom of the instrument indicates to the user what quantity is being displayed. The Alphanumeric display also provides the user with primary engineering units (Watts, kWatts, MWatts, etc.). The Middle Display of the M663 retains all the functionality of the M660 Display including Scrolling, Home Screen designation, Custom screens, Setup mode, etc. The M663 adds a Left Display, a Right Display, a Left Button and a Right Button to the front panel. All three displays can display several per-phase and total quantities for the circuit being monitored. Any pre-defined or custom screen that is displayed on the Middle Display can be copied to the Left or Right Display by pressing the corresponding Left or Right button on the front panel. The last selection made is retained through power down events. In addition to the front panel buttons, the screen selection for the Left and Right Display may be made on the Settings/Screen Enable webpage. The screens that appear on the left and right displays do not need to be enabled on the middle display. Listed on the following pages are standard screens available in the M66X (note that demand and harmonic summary screens are only available in model M3). Configurable screen enable settings allow the user to enable or disable each of the display screens, in order to view only a selected subset of all the measurements the meter is capable of displaying. Refer to the section in this manual on Setup Mode for instructions on programming Screen Enable Settings (Setup menu - ^{1.6} Scrn Ena).

The following screens are enabled by default:

Amps A,B,C
Volts AN,BN,CN
Volts AB,BC,CA
Total Watts / Total Vars
VAs Total / Power Factor
Frequency
Demand Amps A,B,C

The Default HOME screen is:

Amps A,B,C.

INSTANTANEOUS DISPLAY SCREENS

	Format	Quantity
1.	00000 00000 00000 AmpsΦ	Phase A Amperes Phase B Amperes Phase C Amperes
2.	00000 □□□□□ □□□□□ AmpsR	Residual Amperes ¹ Unused Unused
3.	00000 00000 00000 xVolts	Phase A Volts ¹ Phase B Volts Phase C Volts
4	00000 00000 00000 xVolts	Phase A-B Volts Phase B-C Volts Phase C-A Volts
5.	00000 00000 00000 xWatts Φ	Phase A Watts ¹ Phase B Watts Phase C Watts
6.	00000 00000 00000 xVAR Φ	Phase A VARs ¹ Phase B VARs Phase C VARs
7.	00000 00000 □□□□□ xW·xVAR	Total Watts Total VARs Unused

8.	00000	Phase A VAs ¹
	00000	Phase B VAs
	00000	Phase C VAs
	xVA Φ	

9.	00000	Phase A PF ¹
	00000	Phase B PF
	00000	Phase C PF
	PF Φ	

10.	00000	Total VAs
	00000	3 Φ PF
	□□□□□	Unused
	xVAs·PF	

11.	00.000	Frequency
	□□□□□	Unused
	□□□□□	Unused
	Hz	

12.	12345	\ Positive
	6789A.	/ kWh
	□□□□□	Unused
	+kWh	

13.	12345	\ Negative
	6789A.	/ kWh
	□□□□□	Unused
	-kWh	

14.	12345	\ Positive
	6789A.	/ kVARh
	□□□□□	Unused
	+kVARh	

15.	12345	\ Negative
	6789A.	/ kVARh
	□□□□□	Unused
	-kVARh	

- | | | |
|-----|----------|---|
| 16. | 000.00 | VA hours (Most significant half) |
| | 000.00 | VA hours (Least significant half) |
| | □□□□□ | Unused |
| | kVAh | |
| | | |
| 17. | 00000 | Watt hours Net (Most significant half) |
| | 00000 | Watt hours Net (Least significant half) |
| | □□□□□ | Unused |
| | kWh NET | |
| | | |
| 18. | 00000 | Total Watts |
| | 00000 | 3Φ PF |
| | 0000 | Frequency |
| | xW·PF·Hz | |

¹ - Screen available on WYE meters only
x - indicates blank, (k)ilo, (M)ega, or (G)iga

DEMAND DISPLAY SCREENS

	Format	Quantity
19.	000.00 000.00 000.00 Amps Dmd	Phase A Amps Demand Phase B Amps Demand Phase C Amps Demand
20.	00000 00000 00000 Amps MAX	Phase A Maximum Amperes Demand Phase B Maximum Amperes Demand Phase C Maximum Amperes Demand
21.	000.00 000.00 □□□□□ AmpsDmdR	Residual Amps Demand Maximum Residual Amps Demand Unused
22.	000.00 000.00 000.00 xV Avg	Phase A Average Voltage Phase B Average Voltage Phase C Average Voltage
23.	00000 00000 00000 xV MAX	Phase A Maximum Volts Demand ¹ Phase B Maximum Volts Demand Phase C Maximum Volts Demand
24.	00000 00000 00000 xV MIN	Phase A Minimum Volts Demand ¹ Phase B Minimum Volts Demand Phase C Minimum Volts Demand
25.	000.00 000.00 000.00 xV Avg	Phase A-B Average Voltage Phase B-C Average Voltage Phase C-A Average Voltage
26.	00000 00000 00000 xV MAX	Phase A-B Maximum Volts Demand Phase B-C Maximum Volts Demand Phase C-A Maximum Volts Demand

- | | | |
|-----|--------------|--------------------------------|
| 27. | 00000 | Phase A-B Minimum Volts Demand |
| | 00000 | Phase B-C Minimum Volts Demand |
| | 00000 | Phase C-A Minimum Volts Demand |
| | xV MIN | |
| | | |
| 28. | 00000 | Total Maximum Watt Demand |
| | 00000 | Total Watts (Also on Screen 7) |
| | 00000 | Total Minimum Watt Demand |
| | xW · ↑ · ↓ | |
| | | |
| 29. | 00000 | Total Maximum VAR Demand |
| | 00000 | Total VARs (Also on Screen 7) |
| | 00000 | Total Minimum VAR Demand |
| | xVAR · ↑ · ↓ | |
| | | |
| 30. | 00000 | Total Maximum VAs |
| | 00000 | Total VAs (Also on Screen 10) |
| | 00000 | Total Minimum VAs |
| | xVA · ↑ · ↓ | |

¹ - Screen available on WYE meters only
x - indicates blank, (k)ilo, (M)ega, or (G)iga

HARMONIC SUMMARY DISPLAY SCREENS

	Format	Quantity
31.	00000 00000 00000 Fnd Amps	Phase A Fundamental Amperes Phase B Fundamental Amperes Phase C Fundamental Amperes
32.	00000 □□□□□ □□□□□ FndN · Amps	Fundamental Residual Amperes ¹ Unused Unused
33.	00000 00000 00000 Fnd xV	Phase A Fundamental Volts Phase B Fundamental Volts Phase C Fundamental Volts
34.	000.00 000.00 000.0 Fnd xV	Phase A-B Fundamental Voltage Phase B-C Fundamental Voltage Phase C-A Fundamental Voltage
35.	000.00 000.00 000.00 %TDD I	Phase A Current %Total Demand Distortion (%TDD) Phase B Current %Total Demand Distortion (%TDD) Phase C Current %Total Demand Distortion (%TDD)
36.	000.00 000.00 000.00 %THD V	Phase A Voltage %Total Harmonic Distortion (%THD) ¹ Phase B Voltage %Total Harmonic Distortion (%THD) Phase C Voltage %Total Harmonic Distortion (%THD)
37.	000.00 000.00 000.00 %THD V	Phase A-B Voltage %Total Harmonic Distortion (%THD) Phase B-C Voltage %Total Harmonic Distortion (%THD) Phase C-A Voltage %Total Harmonic Distortion (%THD)

38.	00.000	K-Factor Phase A (Current)
	00.000	K-Factor Phase B (Current)
	00.000	K-Factor Phase C (Current)
	K-Factor	

¹ - WYE meters only

x - indicates blank, (k)ilo, (M)ega, or (G)iga

HARMONIC SUMMARY DISPLAY SCREENS (Cont'd)

	Format	Quantity
39.	0.0000 0.0000 0.0000 DispPF Φ	Phase A Displacement PF ¹ Phase B Displacement PF Phase C Displacement PF
40.	00000 □□□□□ □□□□□ DispPF T	3 Φ Displacement PF Unused Unused
41.	000.00 000.00 000.00 FndDmdl Φ	Phase A Fundamental Demand Amps Phase B Fundamental Demand Amps Phase C Fundamental Demand Amps
42.	000.00 000.00 000.00 FndDmdl Φ	Phase A Maximum Fundamental Demand Amps Phase B Maximum Fundamental Demand Amps Phase C Maximum Fundamental Demand Amps
43.	000.00 000.00 □□□□□ FundDmdlR	Maximum Fundamental Demand Amps Residual Fundamental Demand Amps Residual Unused
44.	000.00 000.00 000.00 xW Avg	Phase A Average Watts Phase B Average Watts Phase C Average Watts
45.	000.00 000.00 000.00 xW Max	Phase A Maximum Average Watts Phase B Maximum Average Watts Phase C Maximum Average Watts

46.	000.00	Phase A Minimum Average Watts
	000.00	Phase B Minimum Average Watts
	000.00	Phase C Minimum Average Watts
	xW Min	
47.	000.00	Phase A Average VARs
	000.00	Phase B Average VARs
	000.00	Phase C Average VARs
	xVAR Avg	
48.	000.00	Phase A Maximum Average VARs
	000.00	Phase B Maximum Average VARs
	000.00	Phase C Maximum Average VARs
	xVAr Max	
49.	000.00	Phase A Minimum Average VARs
	000.00	Phase B Minimum Average VARs
	000.00	Phase C Minimum Average VARs
	xVAR Min	
50.	000.00	Phase A Average VAs
	000.00	Phase B Average VAs
	000.00	Phase C Average VAs
	xVA Avg	
51.	000.00	Phase A Maximum Average VAs
	000.00	Phase B Maximum Average VAs
	000.00	Phase C Maximum Average VAs
	xVA Max	
52.	000.00	Phase A Minimum Average VAs
	000.00	Phase B Minimum Average VAs
	000.00	Phase C Minimum Average VAs
	xVA Min	

53. 00000 Phase A Secondary Volts¹
 00000 Phase B Secondary Volts
 00000 Phase C Secondary Volts
 SecVolts
54. 00000 Phase A-B Secondary Volts
 00000 Phase B-C Secondary Volts
 00000 Phase C-A Secondary Volts
 SecVolts
55. 000.00 Auxiliary Voltage
 □□□□□ Unused
 □□□□□ Unused
 V aux

¹ - Screen available on WYE meters only
 x - indicates blank, (k)ilo, (M)ega, or (G)iga

The screens that are displayed in the scrolling mode can be programmed (ENABLED/DISABLED) by the user. This programming can be done by using the front panel buttons of the device or through the web server.

Enable/Disable Display Mode Screens via the front buttons on Display:


The Screens can be enabled or disabled (refer to Section 5.5) via the front display buttons by entering the setup mode section and going to the Screen Enable menu (1.6, Scrn Ena). This setup can also be accomplished via the web interface through the Ethernet service port by going to the appropriate setup page.

Enable/Disable Display Mode Screens via the Web Server:

The screens can be enabled or disabled via the web server. (Refer to section 5.6) From the web page, select the Settings tab then click on Screen Enable in the menu list.


For all the Watt, VAR and/or PF displays the "SIGN" of the quantity is indicated by the center segment of the left most digit, which will be illuminated to produce a "-" for negative quantities. Positive quantities will have no polarity indication. This restricts the display to 4 digits in the Watt and/or VAR display, however this is a restriction for the display only, internally the instrument still carries full precision.

4.1.1 Overview – Buttons Functions



1. Pressing any button when the display is scrolling will end the scroll.

Figure 8 – Button functions for Display Mode











1. Setup mode is initiated upon pressing combination of Up Arrow and Exit



Figure 9 – Button functions in Set-up Mode

4.1.2 Keypad Functions for Display Mode

Measurements screens may be stepped through manually by pushing the up and down arrow keys. Pushing the Toggle (Exit) key turns the scroll function off and on. When the scroll function is activated, the measurement screens will automatically step through the user-defined screens. Auto scroll state (ON/OFF) is stored in non-volatile memory. Pressing the Home (Enter) key will bring up the home screen. The factory default home screen will be Amps A, B, C. If a user enables or disables screens via the front display buttons from Setup Mode - 1.6 Scrn Ena, then the home screen will automatically become the 1st enabled screen. The home screen can be setup as any one of the enabled screens by simultaneously pressing the Home (Enter) and Toggle (Exit) buttons when on the desired screen and can also be done through the web server Settings tab.

Table 1 –Button Functions

Button	Display Mode Function	Setup Mode Function
Up Arrow 	Next measurement/value	Next menu item
Down Arrow 	Previous measurement/value	Previous menu item or Y (Yes) when prompted
Home (Enter)  Enter	Scroll to designated home screen	Enter selected submenu (or configuration item), or Increments the highlighted digit when entering number, or IP address, or N (No) when prompted
Toggle (Exit)  EXIT	Toggle Auto Scroll On/Off	Exits current menu selection and moves up to next higher menu level. Returns to display mode on exit from main setup menu
Combination Up and Exit keys  	Enter Setup Mode (Resets and configuration setting are done in the setup menu)	
Combination Up and Down Keys  	Resets Demand Values	

Button	Display Mode Function	Setup Mode Function
Combination Home (Enter) and Toggle (Exit) keys  	Designate the displayed screen as "Home Screen"	

Resets are found in setup menu

4.1.3 Display Error Messages

Error messages from self test are shown on the display (M660). The table below summarizes the errors and the messages displayed:

SELF TEST RESULT SUMMARY FOR 60 SERIES DEVICES

Fault	Fault Indication	Effects of Fault	Corrective Action
Display Overflow	Display flashes 9999	Measured quantity is too large to be displayed. Communication option output may still be accurate, if overload does not exceed meter input ratings	Correct fault external to instrument.
Input gain calibration checksum error	G CAL	Calibration constants for the input gain are in error. The display and the communication option output are reduced in accuracy to approximately +/-3%.	Return to factory for repair
Input phase calibration checksum error	P CAL	Calibration constants for the phase are in error. The display and the communication option output are reduced in accuracy to approximately +/-3%.	Return to factory for repair
Analog outputs calibration checksum error	A CAL	Calibration constants for the analog outputs are in error. The analog output option is reduced in accuracy to approximately +/-3%.	Return to factory for repair
Input Over-Range	CLIP	Peak input quantity exceeds the range of the instrument. Both display and communication option output accuracy reduced by an amount depending upon the degree of over-range.	Verify input signals are within range. If within range, return to factory for repair.
Protocol Configuration Error	P CFG	Instrument protocol configuration may be corrupted and inaccurate. This may cause communication errors.	Reset configuration.
Firmware Download in Progress	FLASH	Will be displayed during download and will disappear shortly after user reboots meter	Reboot meter when prompted.

5.0 FUNCTIONAL DESCRIPTION

5.1 Configuration

Setup of the M66X meters is most easily performed using the web interface via the Ethernet service port. Basic configuration can also be handled from the front display by entering the setup mode.

5.2 HTML Web Server

The M66X incorporates an internet-compatible HTML web page.

5.3 Passwords

Passwords can be setup through the web interface in the 60 Series for use in controlling access to configuration and other functions available through the Ethernet port. Passwords may be comprised of the 95 printable ASCII characters as defined by http://en.wikipedia.org/wiki/ASCII#ASCII_printable_characters which includes 0-9, a-z, A-Z, and special characters with the exception of the tilde character (~). Passwords may have maximum length of 20 characters and a minimum of 1 character. Passwords prompts are disabled by leaving the new password field blank and clicking the 'Change Password' button. The default from the factory is to have no password set.

The password is used to authenticate a session when prompted. The session authentication will last until the user clicks the 'Log Out' link on the upper right corner of the Web Interface or after five minutes elapses. Authentication will be required when attempting the following actions:

- Resetting demand and energy values on the Web Interface Resets page
- Applying changes to any settings on the Web Interface Settings tab
- Uploading new firmware on the Firmware Upload page
- Changing the password on the Password Security page
- Rebooting the IED

The Password Security page includes the Front Panel Configuration Lock, which may be used to prevent access to the following actions:

- Setup Mode on the Front Panel (see section 5.5)
- Demand and Energy Resets from the Front Panel (section 6.10.4).
- Home Screen selection from the Front Panel (section 4.1.2)


There are three options for the Front Panel Configuration Lock as follows:

- Unlocked - All front panel operations are allowed.

- Lock Menu & Resets - Prevents access to the front panel configuration menu as well as reset and home screen shortcuts (see sec 4.1.2).
- Lock Menu only - Prevents access to the front panel configuration menu. Reset and home screen shortcuts are allowed.

If a front panel display action covered under one of the Front Panel Configuration Lock options is attempted while the lock is enabled, the message 'Locked' will be briefly displayed on the front panel alphanumeric display.

If these options are attempted while the lock is enabled, the message 'Locked' will be briefly displayed on the front panel alphanumeric display for M66x.




5.4 Using the M66X with a Bitronics Analog Output Converter

The M66X may be used with any of the Bitronics AOC units (NAO8101, NAO8102, NAO8103, or NAO8104). The AOC may be connected to the serial port. The serial port must be configured for the appropriate protocol and register set for the AOC that will be connected. Setting up the serial ports is accomplished by using the web interface or front buttons. AOC units will only function with the M66X configured for

Optimal Resolution and the Bitronics Legacy register set. When using AOCs that communicate via Modbus (NAO8101 and NAO8102), the M66X serial port must be set for an RxD to TxD Delay of 10ms for proper operation. Serial port and connection information is shown below. Refer to Figure 5 for interconnection. As stated previously, the AOC address must match the protocol address assigned to the M66X communications port.

Protocol	Baud	Parity	Media
DNP	9600	NONE	RS485
Modbus	9600	EVEN	RS485

5.5 Navigating the M660's setup menu from the front panel




SCRN ENA	
[Amps Φ]	Amps A, B C
Amps R]	Amps Reidual
[kVolts Φ]	Volts AN, BN, CN
[kVolts]	Volts AB, BC, C
[Watts Φ]	WattsA, B,C
[kVAR Φ]	VARs A, B, C
[kW·kVAR]	Total Watts· Total VARs
[kVA Φ]	VAs A, B, C
[PF Φ]	Power Factor A, , C
[kVA·PF]	Total VAs · 3 Φ PF
[Hz]	Frequeny
[kWh]	kWatt-Hour Normal(+)
[-kWh]	kWatt-Hours Reverse(-)
[+kVARh]	kVAR-Hous Laggin(+)
[-kARh]	kVA-Hours Leading(-)
[kVAh]	kVA-Hours
[kWhNE]	kWatt-Hours Net
[kW·PF·Hz]	Total Watts · 3 Φ PF · Frequency
[AmpsDmd]	Demand Amps A,B,C
[AmpsDmd	axDmand Amps A,B,C
[AmpsDmdR]	Demand Amps Residual
[VAvg]	Average Volts AN, B, CN
[Vax]	Max verage Vlts AN, BN, CN
[VMin]	Min Average Volts AN BN, CN
[VAvg]	Average Volts AB, BC, CA
[VMax]	Max Aveage Volts AB, BC, CA
[VMin]	Min Average Volts AB, BC, CA

SCREEN ENABLE

...contd.

[kWTot]	Average Watts Max · Total · Min
[kVARTot]	Average VARs Max · Total · Min
[kVATot]	Average VAs Max · Total · Min
[FndAmps]	Fund Amps A, B, C
[FndAmpsR]	Fund Amps Residual
[FndV]	Fund Volts AN, BN, CN
[FndV]	Fund Volts AB, BC, CA
[%TDDI]	TDD Amps A,B,C
[%THDV]	THD Volts AN, BN, CN
[%THDV]	THD Volts AB, BC, CA
[K-Factor]	K-Factor Amps A,B,C
[DispPFΦ]	Displacement Power Factor A,B,C
[DispPFT]	Displacement Power Factor Total
[FndDmdIΦ]	Fund Demand Amps A,B,C
[FndDmdIR]	Max Fund Demand Amps Residual
[FndDmdIΦ]	Max Fund Demand Amps A,B,C
[kWAvg]	Average Watts A, B, C
[kWMax]	Max Average Watts A, B, C
[kWMin]	Min Average Watts A, B, C
[kVARAvg]	Average VARs A. B, C
[kVARMax]	Max Average VARs A. B, C
[kVARMin]	Min Average VARs A. B, C
[kVAAvg]	Average VAs A, B, C
[kVAMax]	Max Average VAs A, B, C
[kVAMin]	Min Average VAs A, B, C
[VAux]	Volts Aux
[SecVolts]	Secondary Volts AN, BN, CN
[SecVolts]	Secondary Volts AB, BC, CA
[All]	All on/off

SCREEN ENABLE



How to Enter an Integer:



Increment highlighted digit by 1.



Highlight Previous/Next digit.



Exit to menu

How to Enter a Floating Point Number:



Increment highlighted digit by 1.



Shifts decimal point one place to right. Decimal moves to left-most digit when right-most digit is passed.



Highlight Next digit. Highlights left-most digit when right-most digit is passed.



Exit to menu

How to Enter an IP address:



Increment highlighted digit by 1.



Highlight Previous/Next digit. Numbers scroll left and right to follow highlighted digit.



Exit to Network menu

5.6 Performing set-up through the web page interface



This section will assume you are able to use the factory default IP address of 192.168.0.171 to connect to the web page using an HTML web server. If this is not the case you may need to refer to section 3.5.1 (Network settings) and the previous section (Navigating the M66X's setup menu from the Front panel) to change your network configuration settings.

Enter the M66X's IP address into your internet browser to connect with the M66X web page interface. Internet browsers supported are Firefox, Internet Explorer, Safari and Google Chrome. The Home page screen should appear as shown below.

Home page:



From the home screen you can select from the following tabs:

Data – This page displays current data measurements

Resets – This page allows certain quantities to be reset

Settings – This page allows the user to change the configuration settings. Making M66X configuration changes require the unit to be rebooted. Configuration settings for the M66X are stored in flash memory.

Contact – This page indicates how to contact Bitronics

NOTE: Some screen shots shown below may not exactly match the appearance of those from your actual meter.

Data page: Three views – Instantaneous, Demands and Trend Log

Live Data View

Instantaneous Demands

	Amps	Volts		Volts
Phase A	0.000	123.29	A-B	0.08
Phase B	0.000	123.29	B-C	0.11
Phase C	0.000	123.33	C-A	0.09
Residual	0.000			

	Watts	VARs	VAs	PF
Phase A	0.0	0.0	0.0	0.000
Phase B	0.0	0.0	0.0	0.000
Phase C	0.0	0.0	0.0	0.000
Total	0.	0.	0.	0.000

Energy Used (+kWh)	101
Energy Produced (-kWh)	121
Energy Lag (+kVARh)	154
Energy Lead (-kVARh)	76

VT Scaling	1.0000 : 1.
CT Scaling	5.0000 : 5.

Frequency	60.013	Health	0000 0000
-----------	--------	--------	-----------

Time Between Polls	1.004 sec	Heartbeat	12
--------------------	-----------	-----------	----

Live Data View

Instantaneous Demands

Amps

	Maximum	Present Demand	
Phase A	0.000	0.000	Amps
Phase B	0.000	0.000	Amps
Phase C	0.000	0.000	Amps

Volts

	Maximum	Present Demand	Minimum	
Phase A	123.70	123.57	0.00	Volts
Phase B	123.71	123.57	0.00	Volts
Phase C	123.74	123.61	0.00	Volts

Total Power

	Maximum	Present Demand	Minimum	
Watts	0.	0.	0.	Watts
VARs	0.	0.	0.	VARs
VAs	0.	0.	0.	VAs

Bitronics

Home Data Resets Settings Status Contact

Trend Log

Instantaneous Demands Vector Diagram Synchronizing Trend Log

First Record	Last Record	Record Count
Thu, 26 Oct 2017 13:56:19 GMT	Thu, 26 Oct 2017 14:16:19 GMT	5

Retrieve Trend Records

☒ Retrieve all records
☐ Retrieve record range

Start: Thu Oct 26 2017 13:56:19.134
 End: Thu Oct 26 2017 14:16:19.142


Download CSV

What do you want to do with trendlog.csv (1.8 KB)?
From: 192.168.0.171

Open Save ^ Cancel X

The data page for trend recording gives information about the trend record, but also provides for retrieving it, or part of it via start and end times, in .csv format.

Resets page: From this page select the quantity to be reset and click apply. Optionally, Energy values can be reset to specific non-zero values by entering the desired reset value in the appropriate field as a whole number and clicking Apply. Any fields that are left blank will be reset to zero.



[Home](#) [Data](#) [Resets](#) [Settings](#) [Status](#) [Contact](#)

Resets

Amps

☐

Volts

☐

Power

☐

Energy

☐

Reset-to-value (optional)

Energy Used (+kWh)

Energy Produced (-kWh)

Energy Lag (+kVARh)

Energy Lead (-kVARh)

Energy (kVAh)

Note: Leaving field blank resets measurement to 0.

Apply

Copyright © 2015 Bitronics, LLC. All rights reserved.

Settings page: Click on one of the settings categories (Identity, Input, Network, Protocol, etc.) to be taken to the next page.



[Home](#) [Data](#) [Resets](#) [Settings](#) [Status](#) [Contact](#)

Device Settings

[Identity](#)
[Input](#)
[Network](#)
[Serial Port](#)
[Protocol](#)
[IEC61850](#)
[Time Sync](#)
[Trend Recorder](#)
[Screen Enable](#)
[Custom Screens](#)
[Load/Store Settings](#)
[Security](#)
[Firmware Upload](#)

Copyright © 2017 Bitronics, LLC. All rights reserved.

Settings Page Selections:

From the Settings page screen you can select one of the following selections:

Identity– This page allows the user to enter information that is necessary to identify the meter. It gives an identity to a particular M66X. Each M66X should have different information entered for its identity.

Input – This page allows for the selection of wiring configuration, setup of CT and PT ratios, demand intervals, and TDD denominator. If option ordered, it also allows setup of parameters for the KYZ pulse output.

Network – This page allows the user to change the network configuration settings for IP address, gateway and router address.

Serial Port – This page allows user configuration for the serial port settings. Note that if no serial port is ordered this setting won't appear.

Protocol – This page allows user configuration of the protocols – DNP or Modbus

IEC61850 – This page allows user to download and upload ICD and CID files

Time Sync – This page allows you to set the 60 Series to the PC time, a user-defined time, or to setup SNTP Time Synchronization

Screen Enable - Allows the screens shown on the M660 display (front panel) to be enabled or disabled by the user.

Custom Screens – Allows the user to set up custom display screens if the standard screens don't meet their needs.

Load/Store Settings – This page allows you to save and retrieve settings for the M66X meter

Password Security – This page allows the user to set a password and to enable or disable access to front display configuration (M660)

Firmware Upload – This page allows the user an interface to browse for or type in the location on their PC of new firmware for purposes of uploading to the unit.

Trend Recorder – This page allows for configuring the trend recorder settings.

EtherNet/IP Device Configuration – Enables or disables this capability if option is purchased and allows for setting an Encapsulation Inactivity Timeout. Please refer to section 4 of the PowerPlex II and 60 Series EtherNet/IP Protocol Manual, ML0048 for more information.

Screen shots showing the selections to be made for each of the above selections follow on the next few pages. Default values are shown where applicable.

M66X configuration changes require the unit to be rebooted. Configuration settings for the M66X are stored in flash memory.

Identity:



Home

Data

Resets

Settings

Status

Contact

[Settings](#) / Identity

Identity

Name

Mx60_name

Description

Mx60_desc

Owner

Mx60_owner

Location


Mx60_locat

Apply

Restore Defaults

Copyright © 2015 Bitronics, LLC. All rights reserved.

Input:



[Home](#) [Data](#) [Resets](#) [Settings](#) [Status](#) [Contact](#)

[Settings](#) / [Input](#)

IED Input Configuration

Input Configuration

3 Element ▼

VT Ratio

Primary

1.0000

Secondary

1 ▼

CT Ratio

Primary

5.0000

Secondary

5 ▼

Invert CT polarity

☐

Demand Intervals

Amp Demand Interval

900

seconds

Volt Average Interval

60

seconds

Power Average Interval

60

seconds

TDD Denominator

Phase A

5.000

Phase B

5.000

Phase C

5.000

Residual

5.000

Loss Compensation

(Copper Watt Loss)

(Test Current)²

0.00000

(Iron Watt Loss)

(Rated Voltage)²

0.00000

(Copper Var Loss)

(Test Current)²

0.00000

(Iron Var Loss)

(Rated Voltage)⁴

0.00000

System Loss


0.00000

Apply

Restore Defaults

Copyright © 2015 Bitronics, LLC. All rights reserved.

Network:



Home Data Resets **Settings** Status Contact

[Settings](#) / Network

Network Configuration

Hostname

hostname

IP Address

192.168.0.171

Subnet Mask

255.255.255.0

Router Address


192.168.0.1

Apply

Restore Defaults

Copyright © 2015 Bitronics, LLC. All rights reserved.

Serial Port (if option ordered):



Home Data Resets **Settings** Contact

[Settings](#) / Serial Port

Serial Port Configuration

Serial Port Mode

RS232

Baud Rate

9600

Parity

NONE

TX Output Control

min RX-to-RTS Delay

0

milliseconds

RTS-to-TX Delay

0

milliseconds

RTS holdup after TX

0

milliseconds

RS232 Hardware Flow Control

RTS - Modem or Ext RS232/485 Converter

☐

RTR - Null Modem

☒

[Serial Port Diagnostics](#)

Apply

Restore Defaults

Protocol Selection: Modbus and DNP3

First select between Modbus or DNP3. You will then select Optimal Resolution (default) or Primary Units. Next you will choose a session. Under Type, there will be 4 different selections for Modbus and 3 for DNP3. Under Modbus the options are Disabled, TCP, ASCII, or RTU. For DNP3 the selections are Disabled, Serial, or TCP. Under DNP3, clicking on the Advanced button reveals more advanced functions that may or may not need to be changed. Clicking on the Basic button hides the advanced functions. A detailed description of the setup parameters for Modbus and DNP3 can be found in the Appendix of the respective protocol manuals.

There are both fixed and configurable register/point lists. Please refer to the appropriate protocol manual for more information regarding how to view or edit the register/point list.

The screenshot shows the Bitronics Protocol Configuration page for Modbus. The 'Protocol' is set to Modbus. Under 'Modbus Protocol Scaling', 'Optimal Resolution' is selected. The scaling factors are: Amps per count (1.0e-4), Volts per count (1.000), and Watts per count (1.000). The 'Modbus Session' is set to 1, Type is TCP, Slave Address is 1, Register Set is TUC1, Tag Register is 0, and Receive Frame Timeout is 4000 milliseconds. The 'TCP/IP' section shows Master IP Address as 0.0.0.0 and IED Listen Port as 502. The 'Legacy Adaptation' section shows Max Holding Regs to Read and Write as 125. Buttons for 'Apply', 'Restore Session Defaults', and 'Restore All Modbus Defaults' are at the bottom.

Home Data Resets **Settings** Status Contact

[Settings](#) / Protocol

Protocol Configuration

Protocol ☒ Modbus ☐ DNP3

Modbus Protocol Scaling ☐ Optimal Resolution ☒ Primary Units

Amps per count 1.0e-4

Volts per count 1.000

Watts per count 1.000

Modbus Session 1

Type TCP

Slave Address 1

Register Set TUC1 [Edit Registers](#)

Tag Register 0

Receive Frame Timeout 4000 milliseconds

TCP/IP

Master IP Address 0.0.0.0

IED Listen Port 502

Legacy Adaptation

Max Holding Regs to Read 125

Max Holding Regs to Write 125

[Apply](#)

[Restore Session Defaults](#)

[Restore All Modbus Defaults](#)

Modbus

The screenshot shows the Bitronics Protocol Configuration page for DNP3. The 'Protocol' is set to DNP3. Under 'DNP3 Protocol Scaling', 'Optimal Resolution' is selected. The scaling factors are: Amps per count (1.000), Volts per count (1.000), and Watts per count (1.000). The 'DNP Session' is set to 1, Type is TCP, IED (Source) is 1, Master (Destination) is 0, Tag Register is 0, Master IP Address is 0.0.0.0, and IED Listen Port is 20000. Buttons for 'Apply', 'Advanced', 'Restore Session Defaults', and 'Restore All DNP Defaults' are at the bottom.

Home Data Resets **Settings** Status Contact

[Settings](#) / Protocol

Protocol Configuration

Protocol ☐ Modbus ☒ DNP3

DNP3 Protocol Scaling ☒ Optimal Resolution ☐ Primary Units

Amps per count 1.000

Volts per count 1.000

Watts per count 1.000

DNP Session 1 [Edit Points List](#)

Type TCP

IED (Source) 1

Master (Destination) 0

Tag Register 0

Master IP Address 0.0.0.0

IED Listen Port 20000

[Apply](#) [Advanced](#)

[Restore Session Defaults](#)

[Restore All DNP Defaults](#)

Copyright © 2015 Bitron

DNP3

Bitronics

Home

Data

Resets

Settings

Status

Contact

Settings

/ Protocol

Protocol Configuration

Protocol

Modbus

DNP3

DNP3 Protocol Scaling

Optimal Resolution

Primary Units

Amps per count

1.000

Volts per count

1.000

Watts per count

1.000

DNP Session

Session

1

Edit Points List

Type

TCP

IED (Source)

1

Master (Destination)

0

Tag Register

0

Master IP Address

0.0.0.0

IED Listen Port

20000

Apply

Basic

Tag Register 1

0

Link Status Period

300

seconds

Validate Source Address

☐

Enable Self Address

☐

Delete Oldest Event

☐

Allow Resets

☒

Allow Time Set

☒

Set Needtime I/I

☒

Deadbands

Phase Current

1.00

Neutral Current

0.10

Voltages

1.00

Power Reactive

1.00

Power Actual

1.00

Frequency

1.00

Miscellaneous

1.00

Timeouts

Needtime

30

minutes

Application Confirm

10000

milliseconds

Select

5000

milliseconds

Unsolicited Response

UR Enable

☐

Enable Initial Null

☐

Class1 Count

5

Class1 Timeout

5000

milliseconds

Class2 Count

5

Class2 Timeout

5000

milliseconds

Class3 Count

5

Class3 Timeout

5000

milliseconds

Max Retries

3

Retry Timeout

5000

milliseconds

Offline Timeout

30

seconds

Default Variations

Binary Input

With flags

Binary Input Event

With absolute time

Binary Output

With flags

Counter

32-bit without flag

Frozen Counter

32-bit with time

Frozen Counter Event

32-bit with time

Analog Input

16-bit without flag

Analog Input Event

16-bit with time

Analog Output Status

16-bit

Transmit/Receive

Receive Fragment Size

2048

Transmit Fragment Size

2048

Receive Frame Size

292

Transmit Frame Size

292

Receive Frame Timeout

15000

milliseconds

First Character Timeout

0

milliseconds

Link Confirm Mode

Never

Link Confirm Timeout

2000

milliseconds

Link Retries

3

Link Offline Poll Period

10000

milliseconds

TCP/IP and UDP

IP Connect Timeout

1000

milliseconds

UDP Broadcast Address

0.0.0.0

UDP Local Port

20000

UDP Destination Port

2

UDP Initial Unsolicited Port

20000

UDP Validate Address

☐

Apply

Restore Session Defaults

Restore All DNP Defaults

DNP TCP Advanced

Protocol Configuration

Protocol ☒ Modbus ☐ DNP3

Modbus Session

Session

Type

Slave Address

Register Set [View Registers](#)

Tag Register

Receive Frame Timeout

Serial

Inter-Character Timeout

Legacy Adaptation

Max Holding Regs to Read

Max Holding Regs to Write

[Apply](#)[Restore Session Defaults](#)

Copyright © 2011 Bitronics LLC. All rights reserved.

Modbus RTU

Protocol Configuration

Protocol ☒ Modbus ☐ DNP3

Modbus Session

Session

Type

Slave Address

Register Set [View Registers](#)

Tag Register

Receive Frame Timeout

TCP/IP

Master IP Address

IED Listen Port

Legacy Adaptation

Max Holding Regs to Read


Max Holding Regs to Write

[Apply](#)[Restore Session Defaults](#)

Copyright © 2011 Bitronics LLC. All rights reserved.

Modbus TCP

IEC61850:



Home Data Resets **Settings** Status Contact

[Settings](#) / IEC61850 Settings

IEC61850 Device Configuration

IEC61850 Settings

61850 Enabled ☒


61850 Disabled ☐

TCP Keepalive seconds

Apply

Restore Defaults

Save Configuration to Computer
Store 61850 configuration files to computer:

[ICD - IED Capability Description \(template\) file](#) Ed. 1 

[CID - Configured IED Description \(configuration\) file](#)

Save CID file to Device


Upload custom CID file

File: No file selected.

OR

Overwrite existing CID with factory demo

Use Factory Demo

Ed. 1 

Copyright © 2015 Bitronics, LLC. All rights reserved.

IED Capability Description (ICD) file: The 60 Series ICD file is an IEC61850 Substation Configuration Language (SCL) file which contains the IEC61850 'capability' description of the 60 Series IED. It is used by the IEC61850 IED Configurator tool to perform an IEC61850 configuration. The ICD file is stored on the M66x IED in flash memory. The ICD file can be downloaded from the IED using the built-in web interface.

The IEC61850 IED Configuration tool uses the ICD file as a template from which it can create an IEC61850 device configuration. After configuration is completed and verified, the user should export that configuration as a CID file to the local PC.

The built-in Web browser in the 60 Series IED is then used to upload the configuration file from the PC and reboot the M66x device. The CID file is stored in flash memory of the M66x device after reboot and will remain the active configuration until a new configuration is uploaded or the user overwrites the configuration with a built-in demo configuration.

The user can select between an Edition 1 or Edition 2 version of the ICD file and can overwrite an existing CID file with either an Edition 1 or Edition 2 version of the factory demo (default) file. The dropdown box only affects which file will be downloaded when the user clicks on the ICD file link. The user does not have to specify which edition of the CID file is being uploaded -- whatever is uploaded will be read and interpreted.

Time Sync:

The time may be set by manually entering the time in the box for “User-defined time” or may be “Set to PC time” by clicking on that selection

The screenshot displays the Bitronics web interface for the Time Sync settings. The header features the Bitronics logo and navigation links: Home, Data, Resets, Settings (active), Status, and Contact. Below the header, the breadcrumb trail reads "Settings / Time Sync". The "IED Time" is shown as "2015/02/13 21:00:02".

The "Manual Time Set" section contains two options:


- Set IED to PC Time:** A button labeled "Set to PC Time".
- Set IED to User-defined Time:** A text input field followed by a "Set Time" button. Below this is a note: "24-hr Time format: [YY]YY/MM/DD hh:mm:ss".

The "SNTP Time Synchronization" section includes:

- External SNTP Server 1:** Input field with "0.0.0.0".
- External SNTP Server 2:** Input field with "0.0.0.0".
- Poll Rate:** Input field with "0" and the unit "seconds".
- Note:** "Poll rate of 0 disables NTP client."
- Buttons:** "Apply" and "Restore Defaults".

The footer contains the copyright notice: "Copyright © 2015 Bitronics, LLC. All rights reserved."

Screen Enable (M660):



[Home](#)
[Data](#)
[Resets](#)
[Settings](#)
[Status](#)
[Contact](#)

[Settings](#) / Screen Enable

Display Screen Enable

	Enabled	Home Screen
Amps A, B, C	<input checked="" type="checkbox"/>	<input checked="" type="radio"/>
Amps Residual	<input type="checkbox"/>	<input type="radio"/>
Volts AN, BN, CN	<input checked="" type="checkbox"/>	<input type="radio"/>
Volts AB, BC, CA	<input checked="" type="checkbox"/>	<input type="radio"/>
Watts A, B, C	<input type="checkbox"/>	<input type="radio"/>
VARs A, B, C	<input type="checkbox"/>	<input type="radio"/>
Total Watts - Total VARs	<input checked="" type="checkbox"/>	<input type="radio"/>
VAs A, B, C	<input type="checkbox"/>	<input type="radio"/>
Power Factor A, B, C	<input type="checkbox"/>	<input type="radio"/>
Total VAs - 3Φ Power Factor	<input checked="" type="checkbox"/>	<input type="radio"/>
Frequency	<input checked="" type="checkbox"/>	<input type="radio"/>
kWatt-Hours Normal(+)	<input type="checkbox"/>	<input type="radio"/>
kWatt-Hours Reverse(-)	<input type="checkbox"/>	<input type="radio"/>
kVAR-Hours Lagging(+)	<input type="checkbox"/>	<input type="radio"/>
kVAR-Hours Leading(-)	<input type="checkbox"/>	<input type="radio"/>
kVA-Hours	<input type="checkbox"/>	<input type="radio"/>
kWatt-Hours Net	<input type="checkbox"/>	<input type="radio"/>
Total Watts - 3Φ PF - Frequency	<input type="checkbox"/>	<input type="radio"/>
Demand Amps A,B,C	<input checked="" type="checkbox"/>	<input type="radio"/>
Max Demand Amps A,B,C	<input type="checkbox"/>	<input type="radio"/>
Demand Amps Residual	<input type="checkbox"/>	<input type="radio"/>
Average Volts AN, BN, CN	<input type="checkbox"/>	<input type="radio"/>
Max Average Volts AN, BN, CN	<input type="checkbox"/>	<input type="radio"/>
Min Average Volts AN, BN, CN	<input type="checkbox"/>	<input type="radio"/>
Average Volts AB, BC, CA	<input type="checkbox"/>	<input type="radio"/>
Max Average Volts AB, BC, CA	<input type="checkbox"/>	<input type="radio"/>
Min Average Volts AB, BC, CA	<input type="checkbox"/>	<input type="radio"/>
Total Watts Max - Avg - Min	<input type="checkbox"/>	<input type="radio"/>
Total VARs Max - Avg - Min	<input type="checkbox"/>	<input type="radio"/>
Total VAs Max - Avg - Min	<input type="checkbox"/>	<input type="radio"/>
Fund Amps A, B, C	<input type="checkbox"/>	<input type="radio"/>
Fund Amps Residual	<input type="checkbox"/>	<input type="radio"/>
Fund Volts AN, BN, CN	<input type="checkbox"/>	<input type="radio"/>
Fund Volts AB, BC, CA	<input type="checkbox"/>	<input type="radio"/>
TDD Amps A,B,C	<input type="checkbox"/>	<input type="radio"/>
THD Volts AN, BN, CN	<input type="checkbox"/>	<input type="radio"/>
THD Volts AB, BC, CA	<input type="checkbox"/>	<input type="radio"/>
K-Factor Amps A,B,C	<input type="checkbox"/>	<input type="radio"/>
Displacement Power Factor A,B,C	<input type="checkbox"/>	<input type="radio"/>
Displacement Power Factor Total	<input type="checkbox"/>	<input type="radio"/>
Fund Demand Amps A,B,C	<input type="checkbox"/>	<input type="radio"/>
Max Fund Demand Amps A,B,C	<input type="checkbox"/>	<input type="radio"/>
Fund Demand Amps Residual	<input type="checkbox"/>	<input type="radio"/>
Average Watts A, B, C	<input type="checkbox"/>	<input type="radio"/>
Max Average Watts A, B, C	<input type="checkbox"/>	<input type="radio"/>
Min Average Watts A, B, C	<input type="checkbox"/>	<input type="radio"/>
Average VARs A, B, C	<input type="checkbox"/>	<input type="radio"/>
Max Average VARs A, B, C	<input type="checkbox"/>	<input type="radio"/>
Min Average VARs A, B, C	<input type="checkbox"/>	<input type="radio"/>
Average VAs A, B, C	<input type="checkbox"/>	<input type="radio"/>
Max Average VAs A, B, C	<input type="checkbox"/>	<input type="radio"/>
Min Average VAs A, B, C	<input type="checkbox"/>	<input type="radio"/>
Secondary Volts AN, BN, CN	<input type="checkbox"/>	<input type="radio"/>
Secondary Volts AB, BC, CA	<input type="checkbox"/>	<input type="radio"/>
Volts Aux	<input type="checkbox"/>	<input type="radio"/>

The M663 is similar but adds the ability to select what is to be displayed on the left and right displays.

Display Screen Enable

	Enabled	Left Display	Home Screen	Right Display
Amps A, B, C	<input checked="" type="checkbox"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
Amps Residual	<input type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Volts AN, BN, CN	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
Volts AB, BC, CA	<input type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Watts A, B, C	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
VARs A, B, C	<input checked="" type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Total Watts - Total VARs	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>

Custom Display Screen Settings (M660): Two Sections – Build/Edit and Summary

The Custom Display Screen Configuration page contains two sections: the Build/Edit panel and the Summary panel. One custom display screen is built at a time in the Build/Edit panel and is then added to the Summary panel, which presents a list of all the custom screens that have been built. The Build/Edit panel is presented if there are no custom screens stored on the IED when the page is loaded; otherwise, the Summary panel is presented. Only one panel is visible at a time.


Build/Edit panel

Select a measurement to be displayed on each display line from the dropdown lists and enter an alphanumeric label that describes the display screen.

Special character buttons insert the characters shown on the buttons into the “Label” field. The “k/M/G” (kilo/Mega/Giga) button inserts an underscore character into the “Label” field, which is automatically replaced with the appropriate unit prefix when displayed on the IED’s front panel. The dot character is used to separate parts of a single label into multiple labels that apply to the different display lines. It is necessary to place dots between underscores that apply to different display lines.

The MIN, MAX, AVG, line and phase LEDs are automatically lit by the IED, based on the selected measurements.

Click the “Next >” button to view the summary panel.



[Home](#) [Data](#) [Resets](#) [Settings](#) [Status](#) [Contact](#)

[Settings](#) / Custom Display Screens

Custom Display Screen Configuration

Measurement

Line 1:

Line 2:

Line 3:

Label

Alphanumeric

Special Characters

Note: Settings are saved to IED upon clicking the "Apply" button on next page.

Copyright © 2015 Bitronics, LLC. All rights reserved.

Summary panel


Screens are saved to IED once the “Apply” button has been clicked. A row (screen) from the summary table can be selected for viewing, editing or deleting by clicking its radio button.

The order of the screens can be changed by selecting a screen from the list and clicking on the up or down arrows.

Custom Display Screen Configuration

Label	Measurement 1	Measurement 2	Measurement 3	Enabled
<input checked="" type="radio"/> 1 _V-A-_Wa	RMS Volts A	RMS Amps A	RMS Watts A	<input checked="" type="checkbox"/>
<input type="radio"/> 2 _V-A-_Wb	RMS Volts B	RMS Amps B	RMS Watts B	<input checked="" type="checkbox"/>
<input type="radio"/> 3 _V-A-_Wc	RMS Volts C	RMS Amps C	RMS Watts C	<input checked="" type="checkbox"/>
<input type="radio"/> 4 kVARh_W	kVAR-Hours Lag	kVAR-Hours Lag	RMS Watts Total	<input checked="" type="checkbox"/>
<input type="radio"/> 5 _V DmdAΦ	Max Demand RMS Volts A	Demand RMS Volts A	Min Demand RMS Volts A	<input checked="" type="checkbox"/>
<input type="radio"/> 6 _V DmdBΦ	Max Demand RMS Volts B	Demand RMS Volts B	Min Demand RMS Volts B	<input checked="" type="checkbox"/>
<input type="radio"/> 7 _V DmdCΦ	Max Demand RMS Volts C	Demand RMS Volts C	Min Demand RMS Volts C	<input checked="" type="checkbox"/>

Load/Store Device Settings:



[Home](#) [Data](#) [Resets](#) [Settings](#) [Status](#) [Contact](#)

[Settings](#) / Load/Store Settings

Load/Store Device Settings

Save to IED
Select a configuration file.

File: No file selected.

☐ Load network & SNTP settings from file


Save to Computer
Store IED configuration to computer.

Restore Factory Defaults
Restore all device settings to factory defaults.

☐ Include network & SNTP settings in restore

Copyright © 2015 Bitronics, LLC. All rights reserved.

Password Security Settings:



[Home](#) [Data](#) [Resets](#) [Settings](#) [Status](#) [Contact](#)

[Settings](#) / Password Security

Change Password

New Password

Retype New Password

Change Password

Note: Submit a blank password to disable password protection.

Front Panel Configuration Lock

Unlocked

☒

Locked

☐

Apply

Copyright © 2015 Bitronics, LLC. All rights reserved.

Firmware Upload:

The screenshot shows the Bitronics web interface. At the top is a dark blue header with the Bitronics logo and navigation links: Home, Data, Resets, Settings (highlighted), Status, and Contact. Below the header, a breadcrumb trail reads 'Settings / Firmware Upload'. The main section is titled 'Update Device Firmware'. It contains the text 'Save to IED' and 'Select a firmware image file.' Below this is a file selection area with a 'File:' label, a 'Browse...' button, the text 'No file selected.', and an 'Upload' button. At the bottom of the page, a copyright notice states 'Copyright © 2015 Bitronics, LLC. All rights reserved.'

Trend Recorder:

The trend recorder allows up to 65 of the 200+ available measurements to be recorded at intervals of once per second or slower. The maximum is 10 measurements at intervals of 30x/sec or 60x/sec (1x every other cycle or 1x per cycle).

The trend log is circular. That is, when the entire trend log memory is full, it wraps around and overwrites the oldest entries in the log. The amount of time that it takes until the log wraps around depends on how much data are written to each log entry and the frequency with which the entries are written. The calculated wrap time is displayed on the trend recorder configuration page and is updated as changes are made to the configuration.



[Home](#) [Data](#) [Resets](#) **[Settings](#)** [Status](#) [Contact](#)

[Settings](#) / [Trend Recorder](#)

Trend Recorder Configuration

Load Settings from File
Select a json file.

File: No file selected.

Save Configuration to Computer
Store trend configuration to computer.

Recorder Enable ☒
Recorder Disable ☐

Recording Interval ☒ Seconds per Entry
☐ Every Sample (60x/sec)
☐ Every Other Sample (30x/sec)

Measurement Type

Measurement List

220 Available	10 Selected
RMS Volts Aux	RMS Volts A 1
RMS Volts A 1	RMS Volts B 1
RMS Volts B 1	RMS Volts C 1
RMS Volts C 1	RMS Amps A 1
RMS Amps A 1	RMS Amps B 1
RMS Amps B 1	RMS Amps C 1
RMS Amps C 1	RMS Volts AB 1
RMS Amps Residual 1	RMS Volts BC 1
RMS Volts AB 1	RMS Volts CA 1
RMS Volts BC 1	System Frequency
RMS Volts CA 1	
RMS Watts A 1	
RMS Watts B 1	
RMS Watts C 1	
RMS Watts Total 1	

>>>

<<<"/>

Trend log will wrap in 1765 days 7 hours

Copyright © 2017 Bitronics, LLC. All rights reserved.

Status Page:

The IED Status page shows the status of the IEC61850 communications interface and the health status. The IEC61850 status states are Operational and Not Running. When the 61850 stack is not running, the reason is displayed. When the 61850 stack is not able to start due to an error, the startup log is displayed for additional detail.

In the M66x, the firmware upgrade and measurements offline bits have been separated. A protocol configuration error bit has also been added.

- 0, "Analog output calibration error"
- 2, "Gain calibration error"
- 4, "Phase calibration error"
- 12, "Firmware upgrade in progress"
- 13, "Measurements offline"
- 15, "Protocol configuration error"



[Home](#) [Data](#) [Resets](#) [Settings](#) [Status](#) [Contact](#)

IED Status

IEC61850 Communications Interface

Status Not running
Reason Deselected by User Option

Health Status

0000 0000

Copyright © 2015 Bitronics, LLC. All rights reserved.



[Home](#) [Data](#) [Resets](#) [Settings](#) [Status](#) [Contact](#)

IED Status

IEC61850 Communications Interface

Status Not running
Reason Error parsing CID file - may be malformed

IEC61850 Startup Log


```
*****  
LOGGING STARTED xxx xxx xx xx:xx:xx xxxx  
*****  
2015-02-18 15:42:31.664 SLOGALWAYS (mms_srvr.c 639)  
MMS-LITE-80X-001 Version 6.0000.3  
2015-02-18 15:42:31.668 SLOGALWAYS (mms_srvr.c 641)  
Initializing ...  
2015-02-18 15:42:34.258 SX_LOG_ERR (sclparse.c 524)  
XML malformed: found , expected  
2015-02-18 15:42:34.260 SX_LOG_ERR (sclparse.c 3907)  
Error 0x8 parsing SCL file (c:\m60.cid)  
2015-02-18 15:42:34.262 SLOGALWAYS (mms_srvr.c 694)  
Error parsing CID file - may be malformed
```

Health Status

0000 0000

Note that if EtherNet/IP option was purchased, there will be a Status page for that. Please refer to section 4 of the PowerPlex II and 60 Series EtherNet/IP Protocol Manual, ML0048 for more information.

Contact Page:



6.0 MEASUREMENTS

Basic measurement quantities are calculated and updated every 100 ms. These quantities include RMS Amperes and RMS Volts, Watts, VARs, VAs, Power Factor, all harmonic-based measurements (such as fundamental-only quantities), Energy, and Frequency, and Phase Angle.

Note: For all of the following measurements, it is important to keep in mind that the specific protocol used to access the data may affect the data that is available, or the format of that data. No attempt is made here to describe the method of accessing measurements - always check the appropriate protocol manual for details.

6.1 Changing Transformer Ratios

The M66X has the capability to store values for Current Transformer (CT) and Potential Transformer (VT) turns ratios. The VT and CT values are factory set to 1:1 CT and 1:1 VT. These values can be entered into the M66X over the network or via front display buttons or web page, and will be stored in internal non-volatile memory. All measurements are presented in primary units, based on these ratios. Please note that the value entered via the front display should be the result of the division of the primary value by 5. For example, for a ratio of 6000:5, you would enter a value of 1200 through the front display. The web interface allows you to choose either 1A or 5A for the denominator, and the primary value is entered directly. The PT ratio is to 1 when entering through the front display. The web allows other denominators (110, 115, or 120) to be used. Refer to the appropriate protocol manual for more information on changing transformer ratios.

6.2 Current

The M66X has three current inputs, with an internal CT on each channel except in the case where external split-core CTs are used. These inputs can read to 2x nominal ($2I_{\text{RMS}}$ for 1A input, $10I_{\text{RMS}}$ for 5A input (symmetrical)) under all temperature and input frequency conditions. No range switching is used, allowing a high dynamic range.

The current signals are transformer coupled, providing a true differential current signal. Additionally, a continuous DC removal is performed on all current inputs. Instrument Transformer Ratios can be entered for each current input, as described above.

The average of the 3 current phases ($(I_a + I_b + I_c)/3$) is also available on a per cycle basis.

6.2.1 Residual Current

The M66X calculates the vector sum of the three phase currents, which is known as the Residual Current. The Residual Current is equivalent to routing the common current return wire through the neutral current input on systems without separate current returns for each phase.

6.3 Voltage Channels

All voltage inputs are measured relative to a common reference level (essentially panel ground). See Appendix 1 for input connection information. Common mode signals can be removed by signal processing algorithms, instead of the more traditional difference amplifier approach. This greatly simplifies the external analog circuitry, increases the accuracy, and allows measurement of the Neutral-to-Ground voltage at the panel. The 7kV input divider resistors are accurate to within +/- 25ppm/DegC, and have a range of 400V_{PEAK}, from any input to panel ground. Each sample is corrected for gain using factory calibration values stored in non-volatile memory on the board. Additionally, a continuous DC removal is performed on all inputs.

The advantages of this method of voltage measurement are apparent when the M66X is used on the common 2, 2½, and 3 element systems (refer to Section 6.5). The M66X is always calculating Line-to-Neutral, and Line-to-Line voltages with equal accuracy. On 2 element connections, any phase can serve as the reference phase.

On 2½ element systems, one of the phase-to-neutral voltages is missing, and the M66X must create it from the vector sum of the other two phase-to-neutral voltages. In order to configure the M66X for 2½ element mode and which phase voltage is missing, select one of the following: 2.5 element - A, 2.5 element - B, or 2.5 element - C.

The average of the 3 voltage phases $((V_a + V_b + V_c)/3)$ is also available and is made available on a per cycle basis.

6.4 Voltage Aux

The M66X M3 provides a measurement for the voltage connected to the power supply terminals. This is a differential voltage. The value can be AC or DC depending upon the power supply voltage source.

6.5 Power Factor

The per-phase Power Factor measurement is calculated using the "Power Triangle", or the per-phase WATTS divided by the per-phase VAs. The Total PF is similar, but uses the Total WATTS and Total VAs instead. The sign convention for Power Factor is shown in Figure 10.

6.6 Watts / Volt-Amperes (VAs) / VARs (Uncompensated)

On any power connection type (2, 2½, and 3 element), the M66X calculates per-element Watts by multiplying the voltage and current samples of that element

together. This represents the dot product of the voltage and current vectors, or the true Watts. The per-element VAs are calculated from the product of the per-element Volts and Amps. The per-element VARs are calculated from fundamental VARs.

In any connection type, the Total Watts and Total VARs is the arithmetic sum of the per-element Watts and VARs. The sign conventions are shown in Figure 10.

When used on 2-element systems, the reference phase voltage (typically phase B) input, is connected to the Neutral voltage input, and effectively causes one of the elements to be zero. ***It is not required to use any particular voltage phase as the reference on 2-element systems. When used on 2-element systems the per-element Watts, VARs, and VAs have no direct physical meaning***, as they would on 2½ and 3 element systems where they represent the per-phase Watts, VARs, and VAs.

When used on 2½ element systems, one of the phase-to-neutral voltages is fabricated, as described in Section 6.3. In all other respects, the 2½ element connection is identical to the 3 element connection.

6.6.1 Geometric VA Calculations

$$GEOMETRIC\ VA_{TOTAL} = \sqrt{Watts_{TOTAL}^2 + VARs_{TOTAL}^2}$$

This is the traditional definition of Total VAs for WYE or DELTA systems, and is the default method for Total VAs calculation. The value of Total VAs calculated using this method does not change on systems with amplitude imbalance, relative to a balanced system.

There is also a relationship to the Total Power Factor, which is described in Section 6.4. Total Power Factor calculations using the Geometric VA method will still indicate a "1" on a system with phase amplitude imbalance, or canceling leading and lagging loads.

For example, on a system with a lagging load on one phase and an equal leading load on another phase, the Geometric VA result will be reduced relative to a balanced system but the Total Power Factor will still be "1".




Figure 10 - Sign Conventions for Power Measurements
(P is Power, Q is VARS and S is VA)

6.7 Compensated Watts and VARs (Line and Transformer Loss Compensation)

The total Watt and Var losses can be calculated using five user entered parameters and measured current and voltage values. These losses are added or subtracted to/from the measured Total Watts and Total Vars when accumulating Energy.

Loss compensation on the M66X takes the following general form:

$$P_{COM} = P_{UNC} + A \cdot I^2 + B \cdot V^2 + E \cdot P_{UNC}$$
$$Q_{COM} = Q_{UNC} + C \cdot I^2 + D \cdot V^4 + E \cdot Q_{UNC}$$

Where:

- P_{COM} Compensated three-phase total watts. Note the accumulators for +kWh and – kWh in the M66X are calculated by integrating the P_{COM} measurement over time.
- P_{UNC} Uncompensated three-phase total watts measured at the point where the meter is connected.
- Q_{COM} Compensated three-phase total VARs. Note the accumulators for +kVARh and – kVARh in the M66X are calculated by integrating the Q_{COM} measurement over time.
- Q_{UNC} Uncompensated three-phase total VARs measured at the point where the meter is connected.
- I RMS line current measured at the point where the meter is connected.
- V RMS *line-line* voltage measured at the point where the meter is connected.
- A **Meter setting** that accounts for the sum of the full-load-watt-losses from all sources.
- B **Meter setting** that accounts for the transformer's no-load-watt-losses.
- C **Meter setting** that accounts for the sum of the full-load-VAR-losses from all sources.
- D **Meter setting** that accounts for the transformer's no-load-VAR-losses.
- E **Meter setting** that accounts for any “system” losses, proportional to the uncompensated power.


Configuring the meter to perform loss compensation simply requires the user to calculate the coefficients A , B , C , D , and E defined above, and enter them in the appropriate fields in the M66X's webserver interface on the Settings/Input page as shown in the screen shot below

The *sign* of the settings A , B , C , D , and E determines whether losses will be added to or subtracted from the uncompensated measurements in order to determine the compensated power and energy. To add losses, be sure the settings are all positive. To subtract losses, be sure the settings are all negative. Settings should always have the same sign.

Making all of the settings equal to zero *turns off* loss compensation.

System losses (E) are a fixed percentage, mutually agreed upon between two electric utilities, about an interchange point that lies on a branched line. As such, E is not a physical property of any particular line, transformer or the meter, so no further

guidance on how best to calculate the coefficient E can be provided here. All instructions following will be concerned only with the calculation of the coefficients A , B , C , and D . Users who do not intend to use system losses should simply set E equal to zero.



A detailed application note on loss compensation in the 50 and 60 Series can be found in the documentation library of the Novatech website, www.novatechweb.com.

6.8 Energy

Separate values are maintained for both positive and negative Watt-hours, positive and negative VAR-hours, and VA-hours, for each feeder. These energy quantities are calculated every cycle from the Total Watts, Total VARs, and Total VAs, and the values are stored into non-volatile memory every 15 seconds. Energy values may be reset. All values are reset simultaneously. Refer to the appropriate protocol manual for details.

6.9 Frequency

The M66X monitors the change in Phase Angle per unit time using the Phase Angle measurement for the fundamental generated by the FFT. The System Frequency is the frequency of the input used for synchronizing the sampling rate.

6.10 Demand Measurements

The traditional thermal demand meter displays a value that represents the logarithmic response of a heating element in the instrument driven by the applied signal. The most positive value since the last instrument reset is known as the maximum demand (or peak demand) and the lowest value since the last instrument reset is known as the minimum demand. Since thermal demand is a heating and cooling phenomenon, the demand value has a response time T , defined as the time for the demand function to change 90% of the difference between the applied signal and the initial demand value.

For utility applications, the traditional value of T is 15 minutes, although the M66X can accommodate other demand intervals (Section 6.10.5).

The M66X generates a demand value using modern microprocessor technology in place of heating and cooling circuits, it is therefore much more accurate and repeatable over a wide range of input values. In operation, the M66X continuously samples the basic measured quantities, and digitally integrates the samples with a time constant T to obtain the demand value. The calculated demand value is continuously checked against the previous maximum and minimum demand values. This process continues indefinitely, until the demand is reset or until the meter is reset (or power removed and reapplied). The demand reset and power-up algorithms are different for each measurement. These routines are further described in following paragraphs. The maximum and minimum demand values are stored in non-volatile memory on the Host Processor module.

NOTE: Changing VT or CT ratios does NOT reset demand measurements to zero.

Demand Quantity	Phase Reference	Function
Amperes	Phase, Residual	Present, Max
Fundamental Amperes	Phase, Residual	Present, Max
Volts	Phase - Neutral, Phase - Phase	Present, Max, Min
Total Watts (A, B, C, Total)	Phase, Total	Present, Max, Min
Total VARs (A, B, C, Total)	Phase, Total	Present, Max, Min
Total VAs (A, B, C, Total)	Phase, Total	Present, Max, Min

6.10.1 Ampere and Fundamental Ampere Demand

Present Ampere Demands are calculated via the instantaneous measurement data used to calculate the per-phase Amperes.

Upon power-up, all Present Ampere Demands are reset to zero. Maximum Ampere Demands are initialized to the maximum values recalled from non-volatile memory. Upon Ampere Demand Reset, all per-phase Present and Maximum Ampere Demands are set to zero. When Ampere Demands are reset, Fundamental Current Demands are also reset.

6.10.2 Volt Demand

Present Volt Demands are calculated via the instantaneous measurement data used to calculate the per-phase Volts. Upon power-up all Present Volt Demands are reset to zero. The Maximum Volt Demands and Minimum Volt Demands are initialized to the minimum and maximum values recalled from non-volatile memory. In order to prevent the recording of false minimums a new Minimum Volt Demand will not be stored unless two criteria are met. First, the instantaneous voltage for that particular phase must be greater than $20V_{rms}$ (secondary). Second, the Present Demand for that particular phase must have dipped (Present Demand value must be less than previous Present Demand value). Upon Voltage Demand Reset, all per-phase Maximum Voltage Demands are set to zero. Minimum Voltage Demands are set to full-scale.

6.10.3 Power Demands (Total Watts, VARs, and VAs)

Present Total Watt, VAR, and VA Demands are calculated via the instantaneous measurement data. The Total VA Demand calculation type is based on the instantaneous Total VA calculation type (Section 6.6)

Upon power-up, all Present Total Watt, VAR, and VA Demands are reset to the average of the stored Maximum and Minimum values. The Maximum and Minimum Demands are initialized to the minimum and maximum values recalled from non-volatile memory. Upon a demand reset, the Maximum and Minimum Demands are set equal to the Present Total Watt, VAR, and VA Demand values. A demand reset does not change the value of the Present Total Watt, VAR, and VA Demands.

6.10.4 Demand Resets

The demand values are reset in 3 groups: current, voltage, and power. This can be accomplished via the front display or from a web browser.

6.10.5 Demand Interval

The M66X uses 900 seconds (15 minutes) as the default demand interval for current. The default for average volts and average power measurements is 60 seconds. Three separate, independent demand intervals may be set for current, voltage, and power. The range of demand intervals is 10 to 9999 seconds. These settings can be accomplished by using the front display or web server setup.

6.11 Harmonic Measurements

All harmonic and harmonic related measurements are calculated every 100 ms. In the following sections, Harmonic 0 indicates DC, Harmonic 1 indicates the fundamental, and Harmonic N is the nth multiple of the fundamental.

6.11.1 Voltage Distortion (THD)

Voltage Harmonic Distortion is measured by phase in several different ways. The equation for Total Harmonic Distortion (THD) is given in Equation 1. Note the denominator is the fundamental magnitude.

$$\%THD = \frac{\sqrt{\sum_{h=2}^{63} V_h^2}}{V_1} \times 100\%$$

Equation 1 – Voltage THD

6.11.2 Current Distortion (THD and TDD)

Current Harmonic Distortion is measured by phase in several different ways. The first method is Total Harmonic Distortion (THD). The equation for THD is given in Equation 2. Note the denominator is the fundamental magnitude.

$$\%THD = \frac{\sqrt{\sum_{h=2}^{63} I_h^2}}{I_1} \times 100\%$$

Equation 2 – Current THD

Alternatively, Current Harmonic Distortion can be measured as Demand Distortion, as defined by IEEE-519/519A. Demand Distortion differs from traditional Harmonic Distortion in that the denominator of the distortion equation is a fixed value. This fixed denominator value is defined as the average monthly peak demand. By creating a measurement that is based on a fixed value, TDD is a "better" measure of distortion problems. Traditional THD is determined on the ratio of harmonics to the fundamental. While this is acceptable for voltage measurements, where the fundamental only varies slightly, it is ineffective for current measurements since the fundamental varies over a wide range. Using traditional THD, 30% THD may mean a 1 Amp load with 30% Distortion, or a

$$\%TDD = \frac{\sqrt{\sum_{h=2}^{63} I_h^2}}{I_L} \times 100\%$$

Equation 3 – Current TDD

100 Amp load with 30% Distortion. By using TDD, these same two loads would exhibit 0.3% TDD for the 1 Amp load and 30% TDD for the 100 Amp load (if the Denominator was set at 100 Amps). In the M66X, Current Demand Distortion is implemented using Equation 3. The TDD equation is similar to Harmonic Distortion (Equation 2), except that the denominator in the equation is a user-defined number. This number, I_L , is meant to represent the average load on the system. The denominator I_L is different for each phase and neutral and is set by changing the denominator values within the M66X.

Note that in Equation 3, if I_L equals the fundamental, this Equation becomes Equation 2 - Harmonic Distortion. In the instrument this can be achieved by setting the denominator to zero amps, in which case the instrument will substitute the fundamental, and calculate Current THD.

Note that there is a separate, writeable denominator for each current input channel. The TDD Denominator Registers are set by the factory to 5 Amps (secondary), which is the nominal full load of the CT input with a 1:1 CT. These writeable denominators can be used in conjunction with the distortion measurements to obtain the magnitudes of harmonics, in other words, convert from percent to amps. This is simply done by multiplying the percent TDD by the TDD Denominator for that phase, and the result will be the actual RMS magnitude of the selected harmonic(s). This technique can also be used if the THD mode (denominator set to zero) is used, by multiplying the percent THD by the Fundamental Amps for that phase.

6.11.3 Fundamental Current

Fundamental Amps are the nominal component (50/60 Hz) of the waveform. The M66X measures the magnitude of the fundamental amps for each phase. These measurements can be used in conjunction with the distortion measurements to obtain the magnitudes of harmonics, in other words, convert from percent to amps. As was mentioned previously, this is simply done by multiplying the percent THD by the Fundamental Amps for that phase (which is the denominator), and the result will be the actual RMS magnitude of the selected harmonic.

6.11.4 Fundamental Voltage

Fundamental Volts are the nominal component (50/60Hz) of the waveform. The M66X measures the magnitude of the fundamental phase-to-neutral and phase-to-phase volts. These measurements can be used in conjunction with the distortion measurements to obtain the magnitudes of harmonics, in other words, convert from percent to volts. This is simply done by multiplying the percent THD by the Fundamental Volts for that phase (which is the denominator), and the result will be the actual RMS magnitude of the selected harmonic.

Fundamental Volts and Amps can be used in conjunction to obtain Fundamental VAs, and when used with Displacement Power Factor can yield Fundamental Watts and Fundamental VARs.

6.11.5 K-Factor

K-Factor is a measure of the heating effects on transformers, and it is defined in ANSI/IEEE C57.110-1986. Equation 4 is used by the M66X to determine K-Factor, where "h" is the harmonic number and "I_h" is the magnitude of the hth harmonic. K-Factor is measured on each of the three phases of amps, however there is no "Total" K-Factor. K-Factor, like THD and PF, does not indicate the actual load on a device, since all three of these measurements are ratios. Given the same harmonic ratio, the calculated K-Factor for a lightly loaded transformer will be the same as the calculated K-Factor for a heavily loaded transformer, although the actual heating on the transformer will be significantly different.

$$K - Factor = \frac{\sum_{h=1}^{63} I_h^2 \times h^2}{\sum_{h=1}^{63} I_h^2}$$

Equation 4 – K-Factor

6.11.6 Displacement Power Factor

Displacement Power Factor is defined as the cosine of the angle (phi) between the Fundamental Voltage Vector and the Fundamental Current Vector. The sign convention for Displacement Power Factor is the same as for Power Factor, shown in Figure 10.

The Total Displacement Power Factor measurement is calculated using the "Power Triangle", or the three-phase Fundamental WATTS divided by the three-phase Fundamental VAs. The per-phase Fundamental VA measurement is calculated from the product of the per-phase Fundamental Amp and Fundamental Volts values. The three-phase Fundamental VA measurement is the sum of the per-phase Fundamental VA values (Arithmetic VAs).

6.11.7 Phase Angles

The M66x measures the Fundamental Phase Angles for all Currents, Line-to-Neutral Voltages, and Line-to-Line Voltages. The Phase Angles are in degrees, and all are referenced to the V_{A-N} Voltage, which places all Phase Angles in a common reference system. Values are from -180 to +180 Degrees. Note that the phase angles are only available in the TUC register set and use calculation type T8 (see Modbus and DNP3 Protocol manuals for more detail). As with other measurements, the Phase angles can be mapped to analog outputs or used in custom display screens.

6.12 Heartbeat and Health Check

M66x provide a Heartbeat State Counter Register that allows the user to determine the time between successive polls. This counter will increment by the number of milliseconds that have elapsed since the last time the data was updated. Another use of this register is as a visual indicator that the data is changing; it allows users of certain MMIs to identify disruption in the polling of the instrument. The Heartbeat State Counter is a full 32-bit counter that rolls over at 4,294,967,295 (4,294,967 seconds). The counter starts at zero on power-up, and is NOT stored in non-volatile memory.

M66x have several self-tests built in to ensure that the instrument is performing accurately. The results of these self-tests are available in the Health Check register which is a simple 16-bit binary value. Each bit represents the results of a particular self-test, with "0" indicating the test was passed, and "1" indicating the test was failed. If Health status failures occur, the meter may have experienced an operational failure. The table below provides a reference of error codes. The Health Check value shown in the M66x web live data page is a hexadecimal representation of the binary value. For example, a Health Check value of 0000 0014 is the equivalent of the binary value 000000000010100. The "1" shown in bit 2 and bit 4 represents a failed test in those bits which indicates a checksum error for both the gain and phase on the calibration. Contact the factory for further instructions.

Health Check Error Codes	
Bit	Description
0	Checksum error on analog output (either 0-1mA or 4-20mA) calibration constants (Note: NOT APPLICABLE IN M66x only M65x)
2	Checksum error on gain calibration of inputs
4	Checksum error on phase calibration of inputs
12	Indicates firmware download in progress and measurements are offline

6.13 List of Available Measurements & Settings

Available Measurements	
Amps A, B, C, Residual	Heartbeat
Average 3-phase Amps	K-factor Amps A
Average 3-Phase Volts (L-L, L-N)	K-factor Amps B
Average Volts AN, BN, CN, AB, BC, CA	K-factor Amps C
Average (Max.) Volts AN, BN, CN, AB, BC, CA ¹	K-factor Amps Residual
Average (Min.) Volts AN, BN, CN, AB, BC, CA	Meter Type
Average Watts A, B, C, Total	Phase Angle Amps A, B, C
Average (Max.) Watts A, B, C, Total	Phase Angle Volts A, B, C
Average (Min.) Watts A, B, C, Total	Phase Angle Volts AB, BC, CA
Average VARs A, B, C, Total	Power Factor A, B, C, Total
Average (Max.) VARs A, B, C, Total	Protocol Version
Average (Min.) VARs A, B, C, Total	PT Scale Factor
Average VAs A, B, C, Total	PT Scale Factor Divisor
Average (Max.) VAs A, B, C, Total	TDD Amps A, B, C, Residual
Average (Min.) VAs A, B, C, Total	TDD Denominator A, B, C
Class 0 Response Setup	THD Volts AN, BN, CN, AB, BC, CA
CT Scale Factor	Uncompensated VARs, Total
CT Scale Factor Divisor	Uncompensated Watts, Total
Demand (Max.) Amps A, B, C, Residual	VA-Hrs
Demand (Max.) Fund. Amps A, B, C, Residual	VAR-Hrs Lag
Demand Amps A, B, C, Residual	VAR-Hrs Lead
Demand Fundamental Amps A, B, C, Residual ¹	VARs A, B, C, Total
Displacement Power Factor A, B, C	VAs A, B, C, Total
Displacement Power Factor Total	Volts AN, BN, CN, AB, BC, CA
Factory Version Hardware	Volts Aux
Factory Version Software	Watt-Hrs Net
Frequency	Watt-Hrs Normal
Fund. Amps A, B, C, Residual	Watt-Hrs Reverse
Fund. Volts AN, BN, CN, AB, BC, CA	Watts A, B, C, Total
Health	

6.14 Calibration

Routine re-calibration is not recommended or required. A field calibration check every few years is a good assurance of proper operation.

6.15 Instantaneous Measurement Principles

The M66X measures all signals at an effective rate of 64 samples/cycle, accommodating fundamental signal frequencies from 45 to 65Hz depending on model. Samples of all bus signals are taken using a 16-Bit A/D converter, effectively creating 64 "snapshots" of the system voltage and current per cycle.


6.15.1 Sampling Rate and System Frequency

The sampling rate is synchronized to the frequency of any of the bus voltages prioritized as follows: V_{1A-N} , V_{1B-N} , V_{1C-N} . This is the frequency reported as the "System Frequency". The sampling rate is the same for all channels.

APPENDIX

A1 CT/VT Connection Diagrams

Please note that there is an option on the Settings/Input page to invert the CT Polarity (see screen shot clip below). This option is the equivalent of swapping the connections in the connection diagrams below at the HI and LO terminals for each CT input, that is, swapping 7 and 10, 8 and 11, 9 and 12. The effect is a 180 degree phase shift in the current signals.



CT Ratio


Primary 5000.0

Secondary 5 ▼

Invert CT polarity ☐

2 Element, 3 Wire, DELTA Connection (Phase A Reference Shown)
Two Phase CTs Shown, Phase A Current Measured in CT Return

100003R1



2 Element, 3 Wire, DELTA Connection (Phase B Reference Shown)

130002





Figure 11 - Signal Connections – M66X

2-1/2 Element, WYE Connection (Shown with Phase B Voltage Missing)

100004



3 Element, 4 Wire, WYE Connection

100001




Figure 11 - Signal Connections – M66X

A2 Ethernet Troubleshooting


If the Link LED fails to illuminate, this is an indication that there is trouble with the connection and communication will not proceed without solving the problem. If a copper connection is used between the M66X and the hub/switch, check the following items:

1. Verify that the connectors are fully engaged on each end.
2. Verify that the cable used is a "straight-through" cable connected to a "normal" port. Alternatively, a "cross-over" cable *could* be connected to an "uplink" port (this could later cause confusion and is not recommended).
3. Verify that both the M66X and hub/switch are powered.
4. Try another cable.
5. If a long CAT-5 cable is used, verify that it has never been kinked. Kinking can cause internal discontinuities in the cable.
6. If a copper connection is used to an external fiber converter:
7. Verify that the LINK LED on the converter is lit on at least one side. Both sides need to be lit for a valid connection to be established.
8. At least one brand of converters will not output an optical idle unless it receives a forced 10 Mb copper link pulse (for some reason, auto-negotiation pulses confuse it). Some hubs/switches will not output an optical idle unless they receive an optical idle. This then inhibits the converter from outputting a copper link pulse enabling the M66X to link. In this condition, no device completes the link.
9. Verify that the fiber converter(s) and/or fiber hub/switch are matched for the same type of fiber connections. A 100BASE-FX port will NEVER inter-operate with the 10BASE-FL port (fiber auto-negotiation does not exist).
10. On the fiber connection, try swapping the transmit and receive connector *on one end*.
11. Verify that the fiber converter(s) and/or fiber hub/switch use the proper optical wavelength (100BASE-FX should be 1300nm).

A3 Display Screens – Visual Representations (M660)

Screen

1




Amps A, B, C

Phase A Amps

Phase B Amps

Phase C Amps


2



Amp Residual

Amps Residual

3




Volts AN, BN, CN

Volts A

Volts B

Volts C

4




Volts AB, BC, CA

Volts AB

Volts BC

Volts CA

5








Watts A, B, C

Watts A

Watts B

Watts C



- 11 **Frequency**
- | | |
|--------|-----|
| 00.000 | MAX |
| | A |
| | A-B |
| | AVG |
| | B |
| | B-C |
| | MIN |
| | C |
| | C-A |
| Hz | |
- 12 **Watt Hrs Normal (+)**
- | | |
|-------|-----|
| 12345 | MAX |
| | A |
| | A-B |
| 6789A | AVG |
| | B |
| | B-C |
| | MIN |
| | C |
| | C-A |
| +kWh | |
- 13 **Watt Hrs Reverse (-)**
- | | |
|-------|-----|
| 12345 | MAX |
| | A |
| | A-B |
| 6789A | AVG |
| | B |
| | B-C |
| | MIN |
| | C |
| | C-A |
| -kWh | |
- 14 **VAR Hrs Lagging (+)**
- | | |
|--------|-----|
| 12345 | MAX |
| | A |
| | A-B |
| 6789A | AVG |
| | B |
| | B-C |
| | MIN |
| | C |
| | C-A |
| +kVARh | |
- 15 **VAR Hrs Leading (-)**
- | | |
|--------|-----|
| 12345 | MAX |
| | A |
| | A-B |
| 6789A | AVG |
| | B |
| | B-C |
| | MIN |
| | C |
| | C-A |
| -kVARh | |
- Frequency
- Most significant half
- Least significant half
- Most significant half
- Least significant half
- Most significant half
- Least significant half
- Most significant half
- Least significant half

16		kVA Hrs	Most significant half	
			Least significant half	
17		kWatt Hrs Net	Most significant half	
			Least significant half	
18		Total Watts · 3Φ PF · Frequency	Total Watts	
			3Φ PF	
			Frequency	
19		Demand Amps A, B, C	Demand Amps A	
			Demand Amps B	
			Demand Amps C	
20		Max Dmd Amps A,B,C	Dmd Amps A Max	
			Dmd Amps B Max	
			Dmd Amps C Max	

21

00000

MAX

A

A-B

00000

AVG

B

B-C

MIN

C

C-A

AmpsDmdR

Demand Amps Residual

Demand Amps R MX

Dmd Amps R

22

00000

MAX

A

A-B

00000

AVG

B

B-C

00000

MIN

C

C-A

xV Avg

Average Volts AN, BN, CN

Volts A

Volts B

Volts C

23

00000

MAX

A

A-B

00000

AVG

B

B-C

00000

MIN

C

C-A

xV Max

Max Average Volts AN, BN, CN

Volts A

Volts B

Volts C

24

00000

MAX

A

A-B

00000

AVG

B

B-C

00000

MIN

C

C-A

xV Min

Min Average Volts AN, BN, CN

Volts A

Volts B

Volts C

25

00000

MAX

A

A-B

00000

AVG

B

B-C

00000

MIN

C

C-A

xV Avg

Average Volts AB, BC, CA

Volts AB

Volts BC

Volts CA

26 Max Average Volts AB, BC, CA




Volts AB

Volts BC

Volts CA

27 Min Average Volts AB, BC, CA




Volts AB

Volts BC

Volts CA

28 Total Watts Max · Avg · Min




Average Watts Max

Average Watts Avg

Average Watts Min

29 Total VARs Max · Avg · Min




Average VARs Max

Average VARs Avg

Average VARs Min

30 Total VAs Max · Avg · Min




Average VAs Max

Average VAs Avg

Average VA Min

31 Fundamental Amps A, B, C




Fnd Amps A

Fnd Amps B


Fnd Amps C

32 Fundamental Amps Residual



Fnd Amps Residual

33 Fund. Volts AN, BN, CN




Fnd Volts A

Fnd Volts B

Fnd Volts C

34 Fund. Volts AB, BC, CA




Fnd Volts AB

Fnd Volts BC

Fnd Volts CA

35 TDD Amps A, B, C



TDD Amps A

TDD Amps B

TDD Amps C

36

00000

MAX
A
A-B

00000

AVG
B
B-C

00000

MIN
C
C-A

% THD V

THD Volts AN, BN, CN

THD Volts AN

THD Volts BN

THD Volts CN

37

00000

MAX
A
A-B

00000

AVG
B
B-C

00000

MIN
C
C-A

% THD V

THD Volts AB, BC, CA

THD Volts AB

THD Volts BC

THD Volts CA

38

00000

MAX
A
A-B

00000

AVG
B
B-C

00000

MIN
C
C-A

K-Factor

K-Factor Amps A, B, C

K-Factor A

K-Factor B

K-Factor C

39

00000

MAX
A
A-B

00000

AVG
B
B-C

00000

MIN
C
C-A

DispPF Φ

Displacement Power Factor A, B, C

Displacement PF A

Displacement PF B

Displacement PF C

40

00000

MAX
A
A-B

AVG
B
B-C

MIN
C
C-A


DispPF T

Displacement Power Factor Total

Displacement PF T

41		Fund. Demand Amps A, B, C Fnd Dmd Amps A Fnd Dmd Amps B Fnd Dmd Amps C
42		Max Fund. Demand Amps A, B, C Fnd Dmd Amps A Fnd Dmd Amps B Fnd Dmd Amps C
43		Max Fund. Demand Amps Residual Fnd Dmd Amps R Fnd Dmd Amps R
44		Average Watts A, B, C Watts A Watts B Watts C
45		Max Average Watts A, B, C Watts A Watts B Watts C

46 Min Average Watts A, B, C




Watts A

Watts B

Watts C

47 Average VARs A. B, C




VARs A

VARs B

VARs C

48 Max Average VARs A. B, C




VARs A

VARs B

VARs C

49 Min Average VARs A. B, C




VARs A

VARs B

VARs C

50 Average VAs A, B, C




VAs A

VAs B

VAs C

51 Max Average VAs A, B, C



VAs A

VAs B

VAs C

52 Min Average VAs A, B, C




VAs A

VAs B

VAs C

53 Secondary Volts AN, BN, CN




SecVolts A

SecVolts B

SecVolts C

54 Secondary Volts AB, BC, CA




SecVolts AB

SecVolts BC

SecVolts CA

55 Volts Aux



V Aux

EC Declaration of Conformity

This declaration of conformity is issued under the sole responsibility of the manufacturer.

We, the undersigned:

Manufacturer:	Bitronics LLC 261 Brodhead Road Bethlehem, PA 18017-8698 USA T +610.997.5100 F +610.997.5450 E bitronics@novatechweb.com	Authorized Representative in the European Union:	NovaTech Europe BVBA Kontichsesteenweg 71 2630 Aartselaar Belgium T +32.3.458.0807 F +32.3.458.1817 E info.europe@novatechweb.com
----------------------	--	---	---

hereby declare that the following product(s) :

Product type :	50 Series & 60 Series
Description :	Multifunction 3-Phase Scada Meters, Multifunction 3-Phase Scada Transducers, 3-Phase Scada Ammeters and Voltmeters, Detached Display
Models (50 Series):	<p>M65xM3yzef, or M65xB3yzef, (where x=0,1,3) covering M650, M651, or M653, based on the following constructions:</p> <p>with Auxiliary voltage input monitoring (y = P, for models M3 only, but not B3), or without Auxiliary voltage input monitoring (y = U); including Measurement signal inputs for 3-Phase Voltages, and Current (CT) inputs rated for one of the following: Nominal input current of 1A ac or 5A ac (internal isolation for current input options, z = 1 or 5), or External Split Core CT rated 5A ac nominal (current input option z = C); including a 6-position option port selected as one of the following: without option port (e = 0), with serial port (e = 1), with 4-20mA Analog Transducer Output port (e = 2), with 0-1mA Analog Transducer Output port (e = 3), including standard copper RJ45 Ethernet port (f = 0 with service port only, or f = 1 with port enabled for protocols), or an optional fiber Ethernet port (f = 2).</p> <p>M350A3Uzef covering M350A3, based on the following constructions:</p> <p>Ammeters with Measurement signal inputs for 3-Phase Current Transformer (CT) inputs rated nominal input current of 1A ac or 5 A ac (internal isolation for current input options, z = 1 or 5); including a 6-position option port selected as one of the following: without option port (e = 0), with serial port (e = 1), with 4-20mA Analog Transducer Output port (e = 2), with 0-1mA Analog Transducer Output port (e = 3); including standard copper RJ45 Ethernet port (f = 0 with service port only, or f = 1 with port enabled for protocols), or an optional fiber Ethernet port (f = 2).</p> <p>M350V3Uzef covering M350V3, based on the following constructions:</p> <p>Voltmeters with Measurement signal inputs for 3-Phase Voltage inputs (z = 0); including a 6-position option port selected as one of the following: without option port (e = 0), with serial port (e = 1), with 4-20mA Analog Transducer Output port (e = 2), with 0-1mA Analog Transducer Output port (e = 3); including standard copper RJ45 Ethernet port (f = 0 with service port only, or f = 1 with port enabled for protocols) or an optional fiber Ethernet port (f = 2).</p> <p>D650BXy0ef covering D650 based on the following construction:</p> <p>Detached Display without Auxiliary voltage input monitoring (y = U) ; with serial port (e = 1); including standard copper RJ45 Ethernet port (f = 0 with service port only).</p>

Reference Number : DOC B005

Issue : F

Date of issue : 5-December-2016

Form BIDOC_H

Models (60 Series):	M66xM3yzef, (where x=0,1,3) covering M660, M661, or M663, based on the following constructions:
IEC 61850 protocol	with Auxiliary voltage input monitoring (y = P), or without Auxiliary voltage input monitoring (y = U); including Measurement signal inputs for 3-Phase Voltages, and Current (CT) inputs rated for one of the following: Nominal input current of 1A ac or 5A ac (internal isolation for current input options, z = 1 or 5), or External Split Core CT rated 5A ac nominal (current input option z = C); including an Ethernet fiber option port selected as one of the following: without Ethernet fiber port (e = 0) or with Ethernet fiber port (e=5), including standard copper RJ45 Ethernet port (f = 1 with port enabled for protocols).

Conform(s) with the protection requirements of the following directive(s) :

1. European Community Directive on EMC (EMCD) 2014/30/EU, superceding 2004/108/EC, and Directive 91/263/EC [TTE/SES]. Fulfilment of the essential requirements set out in Annex I has been demonstrated.
2. European Community Directive on Low Voltage (LVD) 2014/35/EU, superceding 2006/95/EC. Fulfilment of the safety objectives referred to in Article 3 and set out in Annex I has been demonstrated.

The object of the declaration described above is in conformity with the relevant Union harmonisation legislation: Directives 2004/108/EC & 2006/95/EC (until April 19th, 2016) and Directives 2014/30/EU &, 2014/35/EU (from April 20th, 2016).

The requirements for the following directive(s) were determined to be not applicable

Directive #	Subject of Directive	Reason Directive is Not Applicable
2011/65/EU	Restriction of the Use of Certain Substances in electrical equipment (RoHS)	Not applicable - large scale fixed installation is exempt per Article 2, clause 4e (utility substation equipment which is designed in)
2012/19/EU	Waste Electrical and Electronic (WEEE)	Not applicable - large scale fixed installation is exempt per Article 2, clause 4c (utility substation equipment which is designed in)

Reference Number : DOC B005
Date of issue : 5-December-2016

Issue : F

Form BIDOC_H

The following route(s) were used to establish conformity :

1. **2014/30/EU: (EMCD) In accordance with Article 14, Annex II** (internal production control) supported by a Technical File, superceding 2004/108/EC, in accordance with Article 7, Annex II.

Technical File No. :	TF B005
Date Issued or Revised :	5-Dec-2016 or later - New Legislative Framework & EMC Directive, (Original issue: 13-Jul-2012, Reissued: 28-Oct-2013, 21-Mar-2016)
Conformity Assessment Body : (C.A.B.)	Underwriters Laboratories, LLC, WiSE, Melville Division 1285 Walt Whitman Road, Melville, NY 11747-3081 USA
Compliance Certificate / Test Report:	1001403534, 11ME06423, MC16183, 50 Series, EMC Assessment; 10059253, M66x, EMC Assessment; D650 reliance on preceding reports is based on similar construction with a subset of inputs/parts removed.

2. **2014/35/EU: (LVD) Self Certification** supported by a Technical File, in accordance with Article 12, Annex III (internal production control), superceding 2006/95/EC.

Technical File No. :	TF B005
Date Issued or Revised :	5-Dec-2016 or later - New Legislative Framework & LVD Directive, (Original issue: 13-Jul-2012, Reissued :28-Oct-2013 - transition to IEC 61010-1, Ed. 3, & 21-Mar-2016)
Conformity Assessment Body : (C.A.B.)	UL International (UK) Limited, Wonersh House, The Guildway, Old Portsmouth Road, Guilford, Surrey, GU3 1LR, United Kingdom
Compliance Certificate / Test Report: (Superceded)	CB Certificate No. DK-27045-UL issued by National Certification Body: UL (Demko), Borupvang 5A DK-2750 Ballerup, Denmark / CB Test Report E164178-A1-CB-1, 50 Series/60 Series, Product Safety Assessment
Conformity Assessment Body : (C.A.B.)	Underwriters Laboratories, LLC, Melville Division 1285 Walt Whitman Road, Melville, NY 11747-3081 USA
Compliance Certificate / Test Report:	CB Certificate No. US-22466-UL-A1 supercedes US-22466-UL & US-19849-UL issued by National Certification Body: UL (US), 333Pfungsten Rd., Northbrook, IL 60062, USA / CB Test Reports, E164178-A4-CB-1, including Amendment 1, Correction 2 & 1, supercedes E164178-A1-CB-2 & -1, 50 Series/60Series, Product Safety Assessments

Reference Number : DOC B005


Issue : F

Date of issue : 5-December-2016

Form BIDOC_H

The following standards were used for reference and to establish conformity :

IEC/EN 61010-1, Edition 3, 2010 UL 61010-1, Edition 3, 2012/05/11 CAN/CSA No. 22.2, No. 61010-1-12, Ed. 3, 2012/05/01	Safety requirements for electrical equipment for measurement, control, and laboratory use. Part 1: General requirements
IEC/EN 61010-2-030, Edition 1, 2010 UL 61010-2-030, Edition 1, 2012/05/11 CAN/CSA No. 22.2, No. 61010-2-030-12, Ed. 1, 2012/05/01	Safety requirements for electrical equipment for measurement, control and laboratory use. Part 2-030: Particular requirements for testing and measuring circuits
EN 61326-1: 2013	Electrical Equipment for measurement, control and laboratory use – EMC requirements
EN 61000-6-4: 2007 + A1: 2011	Electromagnetic compatibility Part 6-4: Generic emission standard – Industrial environment.
EN 61000-6-2: 2005 + AC: 2005	Electromagnetic compatibility (EMC) Part 6-2: Generic standards - Immunity for Industrial environments.
EN 55011: 2009 + A1: 2010, EN 55011: 2016, Group 1 Class A	Radiated Emissions Electric Field Strength, AC Powerline Conducted Emissions
EN 55022: 2010 + AC: 2011, EN 55032: 2012 + AC: 2013, EN 55032: 2015 + AC: 2016-07, Group 1 Class A (Conducted on Ethernet port)	Electromagnetic compatibility of multimedia equipment - Emission Requirements
EN 61000-4-2: 2009	Electrostatic Discharge (ESD)
EN 61000-4-3: 2006 + A1: 2008 + A2: 2010 Class III	Immunity to Radiated Electromagnetic Energy (Radio Frequency)
EN 61000-4-4: 2012, Severity Level 4 (AC Power)	Electrical Fast Transient / Burst Immunity
EN 61000-4-5: 2014, Installation Class 3	Surge Immunity
EN 61000-4-6: 2014, Level 3	Immunity to Conducted Disturbances Induced by Radio Frequency Fields
EN 61000-4-8: 2010	Immunity to Power Frequency Magnetic Fields
EN 61000-4-11: 2004	AC Supply Voltage Dips and Short Interruptions
ANSI / IEEE C37.90.1: 2002	Surge Withstand Capability Test for Protective Relays and Relay Systems

Signed for and on behalf of the Company :	Alan Staatz, Vice President, Engineering 
	Novatech, LLC / Lenexa, Kansas USA

CE Marking Year 2012, 2013, 2016

Reference Number : DOC B005
Date of issue : 5-December-2016

Issue : F

Form BIDOC_H

Revision	Date	Changes	By
A	1/16/2015	Original Issue	E. DeMicco
B	2/17/15	Firmware update, new screen shots, changes for configurable TCP keepalive time setting, status tab to web UI, IEC61850 enable/disable control	E. DeMicco
C/D	3/17/15	Firmware update for support of Edition 2 and 100Mb fiber.	E. DeMicco
E	1/24/17	Updated firmware revision history; added new DoC document	E. DeMicco
F	5/22/17	Updated standards information in section 1.5	E. DeMicco R. Fisher
G	9/25/17	Added information on 3-phase average voltages and currents; corrected information on allowable password character; updated revenue accuracy standards.	E. DeMicco
H	3/7/19	Added information on trend recorder, serial port, KYZ pulse and M663, updated time sync and panel lock information	E. DeMicco
J	5/17/19	Added information on 20A ac input option	E. DeMicco
K	10/15/19	Added information for 24 Vdc power supply	E. DeMicco



Bitronics, LLC 261 Brodhead Road, Bethlehem, PA. 18017
(610) 997-5100 Fax (610) 997-5450
www.novatechweb.com/bitronics